

INSTRUMENTATION AND WARNING SYSTEMS

GROUP

13

(10000 & 19000)

SECTION TITLE	PAGE	SECTION TITLE	PAGE
CHARGING SYSTEM GAUGE / WARNING INDICATOR	13-04-1	HORN	13-06-1
CLOCK	13-07-1	INSTRUMENT CLUSTER—CONVENTIONAL	13-01-1
FUEL GAUGE	13-03-1	SPEEDOMETER/ODOMETER	13-02-1
GAUGES, WARNING DEVICES, MISCELLANEOUS—ANALOG	13-09-1	TACHOMETER, OIL PRESSURE GAUGE, COOLANT TEMPERATURE GAUGE AND TURBO BOOST GAUGE	13-05-1

SECTION 13-01 Instrument Cluster—Conventional

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	13-01-1	REMOVAL AND INSTALLATION	
DIAGNOSIS AND TESTING		Heater Control Panel Bulb	13-01-12
Electrical Schematic—Instrument Cluster/Panel Illumination System	13-01-4	Instrument Cluster	13-01-10
System Inspection—Instrument Cluster/Panel Illumination System	13-01-6	Instrument Cluster Bulbs	13-01-11
DISASSEMBLY AND ASSEMBLY		Panel Dimmer Switch	13-01-12
Instrument Cluster	13-01-12	Speed Sensor	13-01-11
		SPECIFICATIONS	13-01-13
		VEHICLE APPLICATION	13-01-1

VEHICLE APPLICATION


Capri.

DESCRIPTION

The instrument cluster contains a speedometer, tachometer, fuel gauge, voltmeter, oil pressure gauge and engine coolant temperature gauge. It also contains warning indicator lamps. A boost gauge is included on turbocharged vehicles. All panel / cluster bulbs are controlled by the panel dimmer switch located on the instrument panel.

DESCRIPTION (Continued)

Non-Turbo Cluster




K17162-A

Item	Part Number	Description	Item	Part Number	Description
1	—	Engine Coolant Temperature Gauge	10	—	Battery Voltage Gauge
2	—	Engine Oil Pressure Gauge	11	—	Fuel Gauge
3	—	Trip Odometer	12	—	Charge System Warning Indicator
4	—	Speedometer	13	—	Brake System Warning Indicator
5	—	Odometer	14	—	Check Engine Warning Indicator
6	—	Trip Odometer Reset Button	15	—	Safety Belt Warning Indicator
7	—	Turn Signal/Hazard Indicator	16	—	Air Bag Warning Indicator
8	—	High Beam Headlamps Indicator	17	—	Manual Shift Indicator (Automatic Transaxle)
9	—	Tachometer			

DESCRIPTION (Continued)

Turbo Cluster




K17163-A

Item	Part Number	Description	Item	Part Number	Description
1	—	Engine Coolant Temperature Gauge	10	—	Battery Voltage Gauge
2	—	Engine Oil Pressure Gauge	11	—	Fuel Gauge
3	—	Trip Odometer	12	—	Charge System Warning Indicator
4	—	Speedometer	13	—	Brake System Warning Indicator
5	—	Odometer	14	—	Check Engine Warning Indicator
6	—	Trip Odometer Reset Button	15	—	Safety Belt Warning Indicator
7	—	Turn Signal/Hazard Indicator	16	—	Air Bag Warning Indicator
8	—	High Beam Headlamps Indicator	17	—	Turbo Boost Gauge
9	—	Tachometer			

DIAGNOSIS AND TESTING

Electrical Schematic—Instrument Cluster/Panel Illumination System


See EVTM for more details
of this circuit



K18625-A


BK

DIAGNOSIS AND TESTING (Continued)




HEADLAMP SWITCH

K18626-A




DIMMER CONTROL SWITCH

K18627-A




ELECTRONIC RADIO

K18628-A




AUDIO SYSTEM RELAY

K18629-A




HEADLAMP LIFT SWITCH

K18630-A



A/C SWITCH

K18631-A



INSTRUMENT CLUSTER

K18632-A

Pin Number	Wire Color	Circuit Function
1A	BK	Ground
1B	GN / W	RH Turn Indicator
1C	BR / Y	Transaxle Control Module (Auto Only)
1D	R / W	High Beam Indicator
1E	BK / Y	Warning Indicator Lamp Power
1F	GN / BK	LH Turn Indicator
1G	Y / R	Oil Pressure Sender
1H	R / GN	Dimmer Control Module

(Continued)

DIAGNOSIS AND TESTING (Continued)

Pin Number	Wire Color	Circuit Function
1I	BK	Ground

(Continued)

Pin Number	Wire Color	Circuit Function
1J	BK	Ground
1K	—	Not Used
1L	Y/W	Temperature Gauge Sending Unit

System Inspection—Instrument Cluster / Panel Illumination System

1. Visually inspect the components. Check for:

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged Components 	<ul style="list-style-type: none"> • Blown Fuses: <ul style="list-style-type: none"> • 60 amp BTN • 30 amp HEAD • 15 amp TAIL • Damage to Wiring Harness • Loose or Corroded Connections

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. If the fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART—INSTRUMENT CLUSTER/PANEL ILLUMINATION SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> • All Lamps Not Operating Correctly 	<ul style="list-style-type: none"> • Fuse(s). • Damaged circuit. • Headlamp switch. • Dimmer control switch. • Audio system relay. • Illumination lamps. 	<ul style="list-style-type: none"> • Go to A1.
<ul style="list-style-type: none"> • Illumination Lamps Not Working Using the Headlamp Switch 	<ul style="list-style-type: none"> • Fuses(s) • Headlamp switch. • Power to the headlamp switch. 	<ul style="list-style-type: none"> • Go to A1.
<ul style="list-style-type: none"> • Some Illumination Lamps Not Operating Correctly 	<ul style="list-style-type: none"> • Damaged circuit. • Dimmer control module. • Audio system relay. • Wires to the illumination lamps. • Blown bulb(s). 	<ul style="list-style-type: none"> • Go to A12.
<ul style="list-style-type: none"> • Audio Illumination and Clock Not Operating Correctly 	<ul style="list-style-type: none"> • Damaged circuit. • Blown bulb(s). • Audio system relay. 	<ul style="list-style-type: none"> • Go to A16.
<ul style="list-style-type: none"> • Some Lamp(s) Not Operating Correctly 	<ul style="list-style-type: none"> • Damaged circuit. • Blown bulb(s). 	<ul style="list-style-type: none"> • Go to A22.

PINPOINT TEST A—INSTRUMENT CLUSTER/PANEL ILLUMINATION SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
A1	CHECK FUSES		
	<ul style="list-style-type: none"> • Locate main fuse panel. • Check 30 amp HEAD fuse and the 60 amp BTN fuse. • Are fuse(s) OK? 	Yes No	GO to A5. GO to A2.
A2	CHECK SYSTEM		
	<ul style="list-style-type: none"> • Replace fuse(s). • Does fuse(s) fail again? 	Yes 30 amp HEAD 60 amp BTN No	GO to A3. GO to A4. GO to A5.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—INSTRUMENT CLUSTER/PANEL ILLUMINATION SYSTEM (Continued)

TEST STEP			RESULT	ACTION TO TAKE												
A3	CHECK FOR SHORTS TO GROUND		Yes No	SERVICE R wire from main fuse panel to headlamp switch. GO to A5.												
<ul style="list-style-type: none">Disconnect positive battery cable.Locate and disconnect main fuse panel connector and headlamp switch.Measure resistance between the R wire at the main fuse panel connector and ground.Is resistance less than 5 ohms?																
A4	CHECK FOR SHORTS TO GROUND		Yes No	SERVICE W/R wire from main fuse panel to headlamp switch. GO to A5.												
<ul style="list-style-type: none">Disconnect the positive battery cable.Locate and disconnect the main fuse panel connector and headlamp switch.Measure resistance between the W/R wire at the main fuse panel connector and ground.Is resistance less than 5 ohms?																
A5	CHECK POWER SUPPLY TO HEADLAMP SWITCH		Yes No	GO to A6. SERVICE wire in question.												
<ul style="list-style-type: none">Disconnect headlamp switch.Measure the voltage on the R and the W/R wires at the headlamp switch?Is voltage(s) greater than 10 volts?																
A6	CHECK HEADLAMP SWITCH GROUND		Yes No	GO to A7. SERVICE BK wire.												
<ul style="list-style-type: none">Key OFF.Measure the resistance between the BK wire at the headlamp switch and ground.Is resistance less than 5 ohms?																
A7	CHECK HEADLAMP SWITCH OPERATION		Yes No	GO to A8. REPLACE headlamp switch.												
<ul style="list-style-type: none">Disconnect headlamp switch.Measure the resistance between the terminals listed in the following switch positions.																
<table><tr><th>Switch Position</th><th>Wire Colors</th><th>Resistance</th></tr><tr><td>OFF</td><td>R, R/GN W/R, W/GN</td><td>Greater than 10,000 ohms Greater than 10,000 ohms</td></tr><tr><td>Parking Lamps</td><td>R, R/GN W/R, W/GN</td><td>Greater than 10,000 ohms Less than 5 ohms</td></tr><tr><td>Headlamps</td><td>R, R/GN W/R, W/GN</td><td>Less than 5 ohms Less than 5 ohms</td></tr></table>			Switch Position	Wire Colors	Resistance	OFF	R, R/GN W/R, W/GN	Greater than 10,000 ohms Greater than 10,000 ohms	Parking Lamps	R, R/GN W/R, W/GN	Greater than 10,000 ohms Less than 5 ohms	Headlamps	R, R/GN W/R, W/GN	Less than 5 ohms Less than 5 ohms		
Switch Position	Wire Colors	Resistance														
OFF	R, R/GN W/R, W/GN	Greater than 10,000 ohms Greater than 10,000 ohms														
Parking Lamps	R, R/GN W/R, W/GN	Greater than 10,000 ohms Less than 5 ohms														
Headlamps	R, R/GN W/R, W/GN	Less than 5 ohms Less than 5 ohms														
<ul style="list-style-type: none">Are resistance(s) OK?																
A8	CHECK WIRE TO INTERIOR FUSE PANEL		Yes No	GO to A9. SERVICE W/GN wire.												
<ul style="list-style-type: none">Locate interior fuse panel.Measure the resistance of the W/GN wire from headlamp switch to the interior fuse panel (15 amp tail fuse).Is resistance less than 5 ohms?																
A9	CHECK FUSE		Yes No	GO to A12. GO to A10.												
<ul style="list-style-type: none">Check the 15 amp TAIL fuse.Is fuse OK?																
A10	CHECK SYSTEM		Yes No	GO to A11. GO to A12.												
<ul style="list-style-type: none">Replace 15 amp TAIL fuse.Headlamp switch in the ON position.Does fuse fall again?																
A11	CHECK FOR SHORTS TO GROUND		Yes No	SERVICE R/BK wire. GO to A12.												
<ul style="list-style-type: none">Disconnect the dimmer control module, audio system relay and interior fuse panel connector.Measure the resistance between the R/BK wire(s) at the interior fuse panel and ground.Is resistance less than 5 ohms?																

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—INSTRUMENT CLUSTER/PANEL ILLUMINATION SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE												
A12	CHECK POWER SUPPLY TO DIMMER CONTROL MODULE														
	<ul style="list-style-type: none">● Locate the dimmer control module.● Headlamp switch in the ON position.● Measure the voltage on the R/BK wire at the dimmer control module.● Is voltage greater than 10 volts?	Yes No	GO to A13. SERVICE R/BK wire.												
A13	CHECK DIMMER CONTROL MODULE GROUND														
	<ul style="list-style-type: none">● Key OFF.● Measure the resistance between the BK wire at the dimmer control module and ground.● Is resistance less than 5 ohms?	Yes No	GO to A14. SERVICE BK wire.												
A14	CHECK OPERATION OF DIMMER CONTROL MODULE														
	<ul style="list-style-type: none">● Headlamp switch in the ON position.● Measure the voltage on the R/GN wire at the dimmer control module while operating the dimmer control switch from low to high illumination. The voltage range should be between 0 volts and 12 volts.● Are voltages in the correct range(s)?	Yes No	GO to A15. REPLACE dimmer control switch.												
A15	CHECK VOLTAGE TO ELECTRONIC RADIO														
	<ul style="list-style-type: none">● Locate and disconnect the electronic radio connector.● Headlamp switch in the ON position.● Measure the voltage on the R/GN wire at the electronic radio connector.● Is voltage greater than 10 volts?	Yes No	GO to A16. SERVICE R/GN wire.												
A16	CHECK POWER SUPPLY TO AUDIO SYSTEM RELAY														
	<ul style="list-style-type: none">● Locate the audio system relay.● Disconnect the audio system relay connector.● Headlamp switch in the ON position.● Measure the voltage on the R/BK wire at the audio system relay connector.● Is voltage greater than 10 volts?	Yes No	GO to A17. SERVICE the R/BK wire.												
A17	CHECK AUDIO SYSTEM RELAY GROUND														
	<ul style="list-style-type: none">● Measure resistance between the BK wire at the audio system relay and ground.● Is resistance less than 5 ohms?	Yes No	GO to A18. SERVICE BK wire.												
A18	CHECK OPERATION OF AUDIO SYSTEM RELAY														
	<ul style="list-style-type: none">● Disconnect audio system relay.● Measure the resistance between the following wire colors (terminals) at the relay: <table><thead><tr><th>Wire Colors</th><th>Resistance</th></tr></thead><tbody><tr><td>Y/BK, O/BK</td><td>Less than 5 ohms</td></tr><tr><td>O/BK, R/GN</td><td>Greater than 10,000 ohms</td></tr></tbody></table> <ul style="list-style-type: none">● Apply 12 volts to the R/BK terminal of the relay.● Ground the BK terminal of the relay.● Measure the resistance between the following wire colors at the relay: <table><thead><tr><th>Wire Colors</th><th>Resistance</th></tr></thead><tbody><tr><td>O/BK, R/GN</td><td>Less than 5 ohms</td></tr><tr><td>O/BK, Y/BK</td><td>Greater than 10,000 ohms</td></tr></tbody></table> <ul style="list-style-type: none">● Are resistances correct?	Wire Colors	Resistance	Y/BK, O/BK	Less than 5 ohms	O/BK, R/GN	Greater than 10,000 ohms	Wire Colors	Resistance	O/BK, R/GN	Less than 5 ohms	O/BK, Y/BK	Greater than 10,000 ohms	Yes No	GO to A19. REPLACE audio system relay.
Wire Colors	Resistance														
Y/BK, O/BK	Less than 5 ohms														
O/BK, R/GN	Greater than 10,000 ohms														
Wire Colors	Resistance														
O/BK, R/GN	Less than 5 ohms														
O/BK, Y/BK	Greater than 10,000 ohms														

DIAGNOSIS AND TESTING (Continued)


PINPOINT TEST A—INSTRUMENT CLUSTER/PANEL ILLUMINATION SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
A19	CHECK WIRE TO ELECTRONIC RADIO		
	<ul style="list-style-type: none"> Disconnect the audio system relay and the electronic radio. Measure the resistance of the Y/BK wire between the audio system relay and the electronic radio. Is resistance less than 5 ohms? 	Yes No	► GO to A20 . ► SERVICE Y/BK wire.
A20	CHECK CONTINUITY OF AUDIO WIRES		
	<ul style="list-style-type: none"> Disconnect the electronic radio connector. Check for continuity on the O/BK wires between the audio system relay, electronic radio, and the digital clock. Is there continuity? 	Yes No	► GO to A21 . ► SERVICE O/BK wire(s).
A21	TEST DIGITAL CLOCK LAMP		
	<ul style="list-style-type: none"> Key OFF. Locate and disconnect the digital clock connector. Apply 12 volts to the O/BK wire terminal at the digital clock. Ground the BK wire terminal. Does digital clock lamp illuminate? 	Yes No	► GO to A22 . ► REPLACE lamp.
A22	CHECK WIRES TO LAMPS		
	<ul style="list-style-type: none"> Key OFF. Locate dimmer control module. Locate each illumination lamp connector. Measure the resistance of the R/GN wires from the dimmer control module to the following lamp connectors: <ul style="list-style-type: none"> Headlamp lift switch Instrument cluster illumination Headlamp switch Fog lamp switch Cigar lighter Air conditioner switch Rear window defroster switch Blower motor switch Are all resistance less than 5 ohms? 	Yes No	► GO to A23 . ► SERVICE R/GN wire(s) in question.
A23	TEST ILLUMINATION BULBS		
	<ul style="list-style-type: none"> Apply 12 volts to the R/GN wire and ground the BK wire at the following lamp connectors: <ul style="list-style-type: none"> Headlamp lift switch Instrument cluster illumination Headlamp switch Fog lamp switch Cigar lighter Air conditioner switch Rear window defroster switch Blower motor switch Selector lever position (4EAT only) Do all lamps operate correctly? 	Yes No	► GO to A24 . ► REPLACE the bulb(s) in question.
A24	CHECK GROUND OF LAMPS		
	<ul style="list-style-type: none"> Measure resistance between the BK wire and ground at the following lamp connectors: <ul style="list-style-type: none"> Headlamp lift switch Instrument cluster illumination Headlamp switch Fog lamp switch Cigar lighter Air conditioner switch Rear window defroster switch Blower motor switch Selector lever position (4EAT only) Are all resistances less than 5 ohms? 	Yes No	► RETURN to condition chart. ► SERVICE BK wire(s) in questions.

REMOVAL AND INSTALLATION**Instrument Cluster****Removal**

NOTE: Federal law requires that a label stating the odometer has been serviced or replaced be affixed to any vehicle that has had its odometer serviced, replaced or reset to zero.

1. Disconnect negative battery cable.
2. Remove radio/heater control bezel, covers from both sides of steering column, and instrument panel bezel. Refer to Section 01-12.
3. Disconnect speedometer cable at transaxle.
4. Remove screws and slide instrument cluster outward.
5. Press lock tab and release speedometer cable from instrument cluster.
6. Remove connectors from rear of cluster.
7. Remove instrument cluster.


**Installation**

NOTE: Prior to connecting speedometer cable to instrument cluster, apply a 4.6mm (3/16 inch) ball of Silicone Damping Grease D7AZ-19A331-A (ESE-M1C171-A) or equivalent in the drive hole of the speedometer head.

1. Apply grease and connect speedometer cable to wiring connectors to instrument cluster. Make sure speedometer lock tab is fully engaged.
2. Slide cluster into place and install screws retaining cluster to instrument panel. Tighten screws to 3-4 N·m (27-35 lb-in).
3. Connect speedometer cable at transaxle.
4. Install instrument panel bezel, covers on each side of steering column, and radio/heater control bezel.

REMOVAL AND INSTALLATION (Continued)

5. Connect negative battery cable.



K14523-B

Item	Part Number	Description
1	044D70	Instrument Cluster Bezel
2	—	Upper Screw (2 Req'd)
3	V810122-S57B	Lower Screw (2 Req'd)
4	044D70	Heater/Radio Bezel
5	—	Lower Screw (3 Req'd)
6	04338	Right Trim Cover
7	04459	Center Trim Cover
8	04338	Left Trim Cover

TK14523B

Speed Sensor**Removal and Installation**


NOTE: On vehicles equipped with speed control, a speed sensor is mounted in the speedometer assembly. If replacement is required, the speedometer assembly must be replaced.

Instrument Cluster Bulbs**Removal and Installation**

1. Remove instrument cluster as outlined.
2. Replace bulb(s).

REMOVAL AND INSTALLATION (Continued)

3. Install instrument cluster as outlined.



K12951-A

Heater Control Panel Bulb**Removal and Installation**

1. Remove heater or A/C control panel assembly. Refer to Section 12-02 or 12-03.
2. Replace bulb.
3. Install heater or A/C control panel assembly. Refer to Section 12-02 or 12-03.



Panel Dimmer Switch

The panel dimmer switch is located on the LH side of the instrument cluster bezel.

Removal

1. Disconnect negative battery cable.
2. Remove instrument cluster bezel. Refer to Section 01-12.
3. Disconnect electrical connector from switch.

4. Depress tabs on both sides of switch and remove from bezel.



K12952-A

Installation


1. Insert switch into bezel.
2. Connect electrical connector to switch.
3. Install instrument cluster bezel.
4. Connect negative battery cable.
5. Check switch for proper operation.

DISASSEMBLY AND ASSEMBLY**Instrument Cluster****Disassembly**

1. Remove instrument cluster as outlined.
2. Release tabs and separate upper housing from lower housing.

DISASSEMBLY AND ASSEMBLY (Continued)

3. Remove screws from back of instrument cluster as shown.




NATURALLY ASPIRATED VEHICLE CLUSTER SHOWN
TURBOCHARGED VEHICLE CLUSTER SIMILAR

K14524-A

NOTE: The gauges are serviced as three subassemblies. Individual gauge mechanisms are not available.

4. Carefully remove the gauge assembly. If necessary, separate the main assembly into one of the three subassemblies for service:
- Fuel / volt gauge assembly.
 - Temperature / oil pressure gauge assembly.
 - Speedometer / tachometer gauge assembly (includes boost gauge on turbocharged vehicles).
5. If necessary, the clear front cover can be removed from the upper housing after removing the two retaining screws.



K14791-A

Assembly

1. Install clear front cover onto upper housing with two retaining screws, if removed.

NOTE: Two short screws are used for the speedometer, three medium screws are used for the boost gauge, and long screws are used in the remaining gauges.

- Assemble the gauge panel and align it on the lower housing.
- Attach the upper housing to the lower housing. Make sure tabs are fully engaged.
- Install instrument cluster into vehicle as outlined.
- Check operation of all gauges and indicator lamps.

SPECIFICATIONS**TORQUE SPECIFICATIONS**

Description	N·m	Lb·in
Cluster Screws	3-4	27-35

SECTION 13-02 Speedometer/Odometer

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	13-02-1	REMOVAL AND INSTALLATION (Cont'd.)	
DIAGNOSIS AND TESTING		Speedometer Cable	13-02-2
System Inspection—Speedometer		Speedometer Cable Core	13-02-4
System	13-02-1	Speedometer Driven Gear	13-02-4
REMOVAL AND INSTALLATION		VEHICLE APPLICATION	13-02-1
Speedometer Assembly	13-02-4		

VEHICLE APPLICATION

Capri.

DESCRIPTION

The speedometer is connected to the differential of the transaxle by a flexible speedometer cable, and a drive gear located inside the transaxle. On vehicles equipped with speed control, a speed sensor is mounted in the speedometer assembly.

The cable drives the speedometer which registers speed in miles per hour and kilometers per hour. The cable also drives an odometer which records distance traveled in miles and tenths of a mile.

The speedometer is not serviced separately. It is part of the speedometer, tachometer and boost gauge assembly. The boost gauge is used only on turbocharged vehicles.

DIAGNOSIS AND TESTING

System Inspection—Speedometer System

1. Visually inspect the components of the speedometer system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> ● Malfunctioning speedometer ● Binding or broken cable ● Cable connections ● Condition of drive gear in transaxle 	<ul style="list-style-type: none"> ● Refer to Section 13-01 for speedometer illumination

2. Check the speedometer cable for signs of wear or breakage.
3. Check the speedometer cable for kinks or misrouting.
4. If the fault is not visually evident, determine the condition and proceed to the following condition chart.

SPEEDOMETER SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
● Speedometer Not Working	<ul style="list-style-type: none"> ● Broken cable. ● Cable connections. ● Damaged speedometer. 	● Go to A1.
● Speedometer Reading Inaccurate	<ul style="list-style-type: none"> ● Binding cable. ● Damaged speedometer. 	● Go to A3.
● Odometer Not Working But Speedometer OK	<ul style="list-style-type: none"> ● Damaged speedometer. 	● Replace speedometer.
● Speedometer Readings Fluctuate	<ul style="list-style-type: none"> ● Binding cable. ● Damaged speedometer. 	<ul style="list-style-type: none"> ● Replace cable. ● Go to A3.
● Speedometer Noisy	<ul style="list-style-type: none"> ● Lack of lubrication on cable. ● Binding cable. ● Damaged speedometer. 	<ul style="list-style-type: none"> ● Lube cable. ● Replace cable. ● Replace speedometer.

DIAGNOSIS AND TESTING (Continued)

SPEEDOMETER DIAGNOSIS

TEST STEP		RESULT	ACTION TO TAKE								
A1	CHECK SPEEDOMETER CABLE										
<ul style="list-style-type: none">● Check the following speedometer cable connections:<ul style="list-style-type: none">— Connection to transaxle— Connection to speedometer● Are connections in satisfactory condition?		Yes No	GO to A2. SERVICE as required.								
A2	CHECK SPEEDOMETER CABLE										
<ul style="list-style-type: none">● Disconnect speedometer cable from the transaxle.● Remove speedometer drive gear from transaxle.● Spin the speedometer cable and inspect the speedometer drive gear.● Are there any concerns present, such as binding cable or broken drive gear teeth?		Yes No	SERVICE cable or gear as required. REPLACE speedometer.								
A3	CHECK SPEEDOMETER CALIBRATION										
<ul style="list-style-type: none">● Verify the chart below:		Yes No	Speedometer system OK. REPLACE speedometer.								
<table border="1"><thead><tr><th>Standard Indication (km/h)</th><th>Allowable Range (km/h)</th></tr></thead><tbody><tr><td>40</td><td>40-44</td></tr><tr><td>80</td><td>80-88</td></tr><tr><td>120</td><td>120-130</td></tr></tbody></table>		Standard Indication (km/h)	Allowable Range (km/h)	40	40-44	80	80-88	120	120-130		
Standard Indication (km/h)	Allowable Range (km/h)										
40	40-44										
80	80-88										
120	120-130										
<table border="1"><thead><tr><th>Standard Indication (MPH)</th><th>Allowable Range (MPH)</th></tr></thead><tbody><tr><td>30</td><td>27.0-34.5</td></tr><tr><td>60</td><td>54.0-69.0</td></tr><tr><td>90</td><td>81.0-103.5</td></tr></tbody></table>		Standard Indication (MPH)	Allowable Range (MPH)	30	27.0-34.5	60	54.0-69.0	90	81.0-103.5		
Standard Indication (MPH)	Allowable Range (MPH)										
30	27.0-34.5										
60	54.0-69.0										
90	81.0-103.5										
<ul style="list-style-type: none">● Do readings fall in the allowable range?											
NOTE: Tire wear and pressure can cause incorrect readings.											


REMOVAL AND INSTALLATION

Speedometer Cable**Removal**

1. Disconnect speedometer cable at transaxle.
2. Remove battery.

3. Remove radio/heater control bezel, covers from both sides of steering column and instrument panel bezel. Refer to Section 01-12.


REMOVAL AND INSTALLATION (Continued)



K14523-B

Item	Part Number	Description
1	044D70	Instrument Cluster Bezel
2	—	Upper Screw (2 Req'd)
3	V810122-S57B	Lower Screw (2 Req'd)
4	044D70	Heater/Radio Bezel
5	—	Lower Screw (3 Req'd)
6	04338	Right Trim Cover
7	04459	Center Trim Cover
8	04338	Left Trim Cover

4. Remove instrument cluster. Refer to Section 13-01.
5. Slide speedometer cable back, and using a thin, flat-bladed screwdriver, release plastic retainer tabs in dash panel.
6. Remove speedometer cable.



K14634-A

REMOVAL AND INSTALLATION (Continued)**Installation**

NOTE: Prior to connecting speedometer cable to instrument cluster, apply a 4.6mm (3/16 inch) ball of Silicone Damping Grease D7AZ-19A331-A (ESE-M1C171-A) or equivalent in the drive hole of the speedometer head.

1. Insert cable into dash panel. Snap plastic retainer into place and attach cable boot to retainer.
2. Route cable through instrument panel.
3. Apply grease to speedometer cable connection on cluster. Position cluster in instrument panel and connect speedometer cable. Make sure speedometer lock tab is fully engaged.
4. Install instrument cluster. Refer to Section 13-01.
5. Install instrument panel bezel, covers on each side of steering column, and radio/heater control bezel. Refer to Section 01-12.
6. Connect speedometer cable at transaxle.
7. Install battery.
8. Check speedometer for proper operation.

Speedometer Cable Core**Removal and Installation**


1. Remove speedometer cable assembly as outlined.
2. Pull core from cable.
3. Install core into speedometer cable.
4. Install speedometer cable as outlined.

Speedometer Driven Gear**Removal**

1. Disconnect cable from speedometer driven gear at transaxle.
2. Remove bolt from driven gear.

NOTE: The speedometer driven gear may stick in transaxle bore. To assist in removing it from transaxle bore, insert a flat-tipped screwdriver or equivalent between transaxle case and speedometer driven gear. Gently pry up until speedometer driven gear is removed from transaxle case.

3. Remove speedometer driven gear and O-ring.

SPEEDOMETER CABLE**SPEEDOMETER DRIVEN GEAR**

K10663-A

Installation

1. Inspect O-ring for nicks or cuts; replace if damaged.
2. Install O-ring onto speedometer driven gear and insert into transaxle bore.
3. Install retaining bolt.
4. Connect cable into speedometer driven gear.


Speedometer Assembly**Removal**

NOTE: Federal law requires that a label stating the odometer has been serviced or replaced be affixed to any vehicle that has had its odometer serviced, replaced or reset to zero.

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.

REMOVAL AND INSTALLATION (Continued)

3. Separate speedometer / tachometer / boost gauge assembly from other gauge assemblies.

**Installation**

CAUTION: The speedometer is calibrated at the factory. Excessive rough handling could disturb calibration.

1. Position speedometer / tachometer / boost gauge assembly to other gauge assemblies.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check speedometer and all other gauges / indicators for proper operation.
5. Attach odometer notice label to vehicle.

SECTION 13-03 Fuel Gauge

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	13-03-1	REMOVAL AND INSTALLATION	
DIAGNOSIS AND TESTING		Fuel Gauge	13-03-4
Electrical Schematic—Fuel Level Indicating		Fuel Tank Sending Unit	13-03-4
System.....	13-03-2	VEHICLE APPLICATION	13-03-1
System Inspection—Fuel Level Indicating			
System.....	13-03-2		

VEHICLE APPLICATION

Capri.



DESCRIPTION

The fuel level indicator gauge pointer is attached to a wire-wound bimetal strip, which, when heated by a signal from the fuel sender unit, produces the appropriate level indication. When the current is low, there is little heating effect and the pointer moves a short distance. As the current increases, it produces a greater heating effect, causing the pointer to move a greater distance.

The fuel gauge is not serviced separately. It is part of the fuel / volt gauge assembly.


DIAGNOSIS AND TESTING

Electrical Schematic—Fuel Level Indicating System



Pin Number	Wire Color	Circuit Function
2A	GN / R	Vehicle Speed Sensor (VSS)
2B	Y / BK	Air Bag Diagnostic Module Indicator
2C	BK	Ground (Vehicle Speed Sensor)
2D	BK / Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN / O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used
2H	BK / Y	Gauge Power
2I	Y / BL	Ignition Coil (Tachometer Pulse)
2J	BK / GN	Ground (Voltage Gauge, Tachometer)

TL8225A



K18633-A

Pin Number	Wire Color	Circuit Function
3A	BR / W	Parking Brake Switch
3B	W / BL	Boost Sensor
3C	LG / R	Powertrain Control Module (PCM)
3D	BK	Boost Sensor
3E	—	Not Used
3F	Y	Fuel Gauge Sending Unit
3G	W / BK	Generator
3H	BK / GN	Ground

System Inspection—Fuel Level Indicating System

1. Visually inspect the components of the fuel level indicating system.

DIAGNOSIS AND TESTING (Continued)

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged fuel gauge 	<ul style="list-style-type: none"> • Blown fuse: <ul style="list-style-type: none"> • 10 amp METER
<ul style="list-style-type: none"> • Damaged fuel gauge sending unit 	<ul style="list-style-type: none"> • Damage to wire harness • Loose or corroded connections

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. Inspect the fuel gauge and the fuel gauge sending unit for obvious opens or shorts causing partial operation.
4. If the fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART—FUEL LEVEL INDICATING SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> • Fuel Gauge Always Reads Empty 	<ul style="list-style-type: none"> • Fuse. • Circuit. • Damaged fuel gauge. • Damaged fuel gauge sending unit. 	<ul style="list-style-type: none"> • Go to A1.
<ul style="list-style-type: none"> • Fuel Gauge Always Reads Full 	<ul style="list-style-type: none"> • Yellow wire shorted to ground. • Damaged fuel gauge. • Damaged fuel gauge sending unit. 	<ul style="list-style-type: none"> • Go to A6.
<ul style="list-style-type: none"> • Fuel Gauge Reads Inaccurately 	<ul style="list-style-type: none"> • Damaged fuel gauge. 	<ul style="list-style-type: none"> • Go to A6.

PINPOINT TEST A—FUEL LEVEL INDICATING SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
A1	CHECK FUSE		
	<ul style="list-style-type: none"> • Locate the interior fuse panel. • Check the 10 amp METER fuse. • Is the fuse OK? 	Yes No	► GO to A4. ► GO to A2.
A2	CHECK SYSTEM		
	<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Key ON. • Does the fuse fail again? 	Yes No	► GO to A3. ► GO to A4.
A3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Disconnect the interior fuse panel connector and instrument cluster connector. • Measure resistance between the BK / Y wire at the interior fuse panel connector and ground. • Is resistance less than 5 ohms? 	Yes No	► SERVICE BK / Y wire. ► GO to A4.
A4	CHECK FOR POWER SUPPLY TO FUEL GAUGE		
	<ul style="list-style-type: none"> • Key ON. • Locate instrument cluster connector. • Measure voltage on the BK / Y wire at the instrument cluster connector. • Is voltage greater than 10 volts? 	Yes No	► GO to A5. ► SERVICE BK / Y wire.
A5	CHECK FUEL GAUGE GROUND		
	<ul style="list-style-type: none"> • Locate and disconnect the instrument cluster connector. • Measure the resistance between the BK / GN wire at the instrument cluster connector and ground. • Is the resistance less than 5 ohms? 	Yes No	► GO to A6. ► SERVICE the BK / GN wire.
A6	CHECK FUEL GAUGE		
	<ul style="list-style-type: none"> • Key ON. • Ground Y wire at the instrument cluster connector. • Does fuel gauge read full? 	Yes No	► GO to A7. ► REPLACE fuel gauge.
A7	CHECK WIRE FOR SHORT TO GROUND		
	<ul style="list-style-type: none"> • Locate and disconnect the instrument cluster connector and fuel gauge sending unit connector. • Measure the resistance between the Y wire at the instrument cluster connector and ground. • Is the resistance less than 5 ohms? 	Yes No	► SERVICE Y wire. ► GO to A8.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—FUEL LEVEL INDICATING SYSTEM (Continued)


TEST STEP		RESULT	ACTION TO TAKE
A8	CHECK FUEL GAUGE WIRE CONTINUITY		
	<ul style="list-style-type: none"> Remove the rear seat cushion. Key On. Ground Y wire at the fuel gauge sending unit. Does fuel gauge read full? 	Yes No	<ul style="list-style-type: none"> GO to A9. SERVICE Y wire between instrument cluster and fuel gauge sending unit.
A9	CHECK FUEL GAUGE SENDING UNIT GROUND		
	<ul style="list-style-type: none"> Measure resistance between the BK wire at the fuel gauge sending unit and ground. Is resistance less than 5 ohms? 	Yes No	<ul style="list-style-type: none"> GO to A10. SERVICE the BK wire.
A10	CHECK FUEL GAUGE SYSTEM		
	<ul style="list-style-type: none"> Key ON. Does fuel gauge system operate correctly? 	Yes No	<ul style="list-style-type: none"> RETURN to condition chart. REPLACE fuel gauge sending unit.

REMOVAL AND INSTALLATION

Fuel Gauge

Removal

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.
3. Separate the fuel / volt gauge from the speedometer / tachometer / boost gauge assembly. (The boost gauge is used only on turbocharged vehicles.)



Installation

CAUTION: The gauges are calibrated at the factory. Excessive rough handling could disturb calibration.

1. Position fuel / volt gauge to speedometer / tachometer / boost gauge assembly.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check all gauges and indicators for proper operation.



Fuel Tank Sending Unit

Removal

1. Remove rear seat cushion. Refer to Section 01-10.
2. Relieve fuel pressure as follows:
 - a. Run engine while disconnecting fuel pump electrical connector.


REMOVAL AND INSTALLATION (Continued)

- b. Allow engine to run until it stalls. Fuel pressure is now relieved.



K14778-A

3. Disconnect fuel pump ground wire from access cover.
4. Remove access cover.
5. Remove and plug supply and return lines.
6. Remove sending unit retaining bolts.
7. Remove sending unit and gasket from fuel tank. Cover opening of fuel tank to prevent contaminants from entering tank.
8. Remove fuel pump. Refer to Section 10-01.



K14780-A

REMOVAL AND INSTALLATION (Continued)**Installation**

1. Install fuel pump onto sending unit. Refer to Section 10-01.
2. Position a new gasket onto fuel tank and install sending unit with retaining bolts.
3. Unplug and connect supply and return lines and secure with clamps.
4. Install access cover.
5. Install fuel pump connector and ground wire.
6. Start engine and check for leaks. Check the operation of the fuel gauge.
7. Install rear seat cushion. Refer to Section 01-10.

SECTION 13-04 Charging System Gauge

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	13-04-1	REMOVAL AND INSTALLATION	
DIAGNOSIS AND TESTING		Voltmeter	13-04-3
Electrical Schematic — Voltage Gauge		VEHICLE APPLICATION	13-04-1
System	13-04-1		
System Inspection — Voltage Gauge			
System	13-04-2		

VEHICLE APPLICATION



Capri.

DESCRIPTION

The voltmeter indicates the voltage potential at the battery. It is not serviceable and must be replaced as part of the fuel / volt gauge assembly.

DIAGNOSIS AND TESTING

Electrical Schematic — Voltage Gauge System



INSTRUMENT CLUSTER L8225-A

Pin Number	Wire Color	Circuit Function
2A	GN/R	Vehicle Speed Sensor (VSS)
2B	Y / BK	Air Bag Diagnostic Module Indicator
2C	BK	Ground (Vehicle Speed Sensor)
2D	BK / Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN / O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used

(Continued)

DIAGNOSIS AND TESTING (Continued)

Pin Number	Wire Color	Circuit Function
2H	BK / Y	Gauge Power
2I	Y / BL	Ignition Coil (Tachometer Pulse)
2J	BK / GN	Ground (Voltage Gauge, Tachometer)

TL8225A

System Inspection—Voltage Gauge System

1. Visually inspect the components of the voltage gauge system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged voltage gauge 	<ul style="list-style-type: none"> • Blown fuse: <ul style="list-style-type: none"> • 10 amp METER • Damage to wiring harness • Loose or corroded connections

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. Inspect the voltage gauge for obvious opens or shorts causing partial operation.
4. If the fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART—VOLTAGE GAUGE SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> • Voltage Gauge Not Working 	<ul style="list-style-type: none"> • Fuse • Circuit • Voltage Gauge 	<ul style="list-style-type: none"> • Go to A1.
<ul style="list-style-type: none"> • Voltage Gauge Always Reads Low 	<ul style="list-style-type: none"> • Circuit. • Damaged voltage gauge. • Charging system. 	<ul style="list-style-type: none"> • Go to A4. • Refer to Section 14-00.
<ul style="list-style-type: none"> • Voltage Gauge Always Reads High 	<ul style="list-style-type: none"> • Damaged voltage gauge. • Charging system. 	<ul style="list-style-type: none"> • Go to A1. • Refer to Section 14-00.
<ul style="list-style-type: none"> • Voltage Gauge Is Inaccurate 	<ul style="list-style-type: none"> • Damaged voltage gauge. 	<ul style="list-style-type: none"> • Go to A1.

PINPOINT TEST A—VOLTAGE GAUGE SYSTEM

TEST STEP	RESULT	ACTION TO TAKE
A1 CHECK FUSE		
<ul style="list-style-type: none"> • Locate interior fuse panel. • Check 10 amp METER fuse. • Is fuse OK? 	Yes No	► GO to A4. ► GO to A2.
A2 CHECK SYSTEM		
<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Key ON. • Inspect the fuse. • Does fuse fall again? 	Yes No	► GO to A3. ► GO to A4.
A3 CHECK FOR SHORTS TO GROUND		
<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Locate and disconnect the interior fuse panel connector and instrument cluster connector. • Measure resistance between the BK / Y wire at the interior fuse panel connector and ground. • Is resistance less than 5 ohms? 	Yes No	► SERVICE BK / Y wire. ► GO to A4.
A4 CHECK POWER SUPPLY TO VOLTAGE GAUGE		
<ul style="list-style-type: none"> • Key ON. • Locate the instrument cluster connector. • Measure the voltage on the BK / Y wire at the instrument cluster connector. • Is voltage greater than 10 volts? 	Yes No	► GO to A5. ► SERVICE BK / Y wire between instrument cluster and interior fuse panel.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—VOLTAGE GAUGE SYSTEM (Continued)


TEST STEP		RESULT	ACTION TO TAKE
A5	CHECK VOLTAGE GAUGE GROUND		
	<ul style="list-style-type: none"> Measure resistance between the BK / GN wire at instrument cluster connector and ground. Is resistance less than 5 ohms? 	Yes No	REPLACE voltage gauge. SERVICE BK / GN wire.

REMOVAL AND INSTALLATION

Voltmeter

Removal

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.
3. Separate the fuel / volt gauge from the speedometer / tachometer / boost gauge assembly. (The boost gauge is used only on turbocharged vehicles.)



Installation

CAUTION: The gauges are calibrated at the factory. Excessive rough handling could disturb calibration.

1. Position fuel / volt gauge to speedometer / tachometer / boost gauge assembly.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check all gauges and indicators for proper operation.

SECTION 13-05 Tachometer, Oil Pressure Gauge, Coolant Temperature Gauge and Turbo Boost Gauge

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION		DIAGNOSIS AND TESTING (Cont'd.)	
Engine Coolant Temperature Gauge	13-05-1	System Inspection — Turbo Boost Gauge	
Oil Pressure Gauge	13-05-1	System	13-05-11
Tachometer	13-05-1	Tachometer	13-05-2
Turbo Boost Gauge	13-05-2	Electrical Schematic — Tachometer	
DIAGNOSIS AND TESTING		System	13-05-2
System Inspection — Oil Pressure Gauge		REMOVAL AND INSTALLATION	
System	13-05-5	Oil Pressure Gauge	13-05-15
Electrical Schematic — Temperature Gauge		Oil Pressure Sending Unit	13-05-15
System	13-05-7	Tachometer	13-05-13
System Inspection — Tachometer System	13-05-2	Temperature Gauge	13-05-13
Electrical Schematic — Oil Pressure Gauge		Temperature Sending Unit	13-05-14
System	13-05-4	Turbo Boost Gauge	13-05-15
System Inspection — Temperature Gauge		Turbo Boost Gauge Sensor	13-05-16
System	13-05-8	SPECIFICATIONS	13-05-16
Electrical Schematic — Turbo Boost Gauge		VEHICLE APPLICATION	13-05-1
System	13-05-11		

VEHICLE APPLICATION

Capri.

DESCRIPTION

Tachometer

The tachometer is an electrically-operated instrument which indicates engine speed in revolutions per minute (rpm). The tachometer range is 0 to 6,500 rpm.

The tachometer is mounted in the instrument cluster assembly. The electrical schematic is shown in the illustration.

The tachometer is not serviced separately. It is part of the speedometer / tachometer / boost gauge assembly. (The boost gauge is used only on turbocharged vehicles).

Oil Pressure Gauge

The oil pressure indicating system consists of a sender unit mounted on the RH side of the engine block and a gauge mounted in the instrument cluster.

When the engine oil pressure is low, the sender resistance is high, resulting in low current flow through the gauge and little pointer movement.

The oil pressure gauge is not serviceable and must be replaced as part of the temperature / oil pressure gauge assembly.

Engine Coolant Temperature Gauge

The engine coolant temperature indicating system consists of a sender unit mounted on the front of the cylinder head and a temperature gauge mounted in the instrument cluster. The sending unit located in the thermostat housing operates the electric fan.

When the engine coolant temperature is low, the sender resistance is high, resulting in low current flow through the gauge and little pointer movement.

NOTE: The temperature gauge is not serviceable and must be replaced as part of the temperature / oil pressure gauge assembly.

DIAGNOSIS AND TESTING (Continued)

CONDITION CHART—TACHOMETER SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
● Tachometer Not Working	● Fuse. ● Tachometer damage. ● Damaged signal wire.	● Go to A1.
● Tachometer Does Not Function But All Cluster Components Do Function Properly	● Tachometer damage. ● Damage to signal wire. ● Open ground wire.	● Go to A4.
● Tachometer Reading Abnormally	● Tachometer damage.	● Go to A7.

PINPOINT TEST A: TACHOMETER SYSTEM


TEST STEP		RESULT	ACTION TO TAKE														
A1	CHECK FUSE																
	<ul style="list-style-type: none">● Locate the interior fuse panel.● Check 10 amp METER fuse.● Is fuse OK?	Yes No	► GO to A4. ► GO to A2.														
A2	CHECK SYSTEM																
	<ul style="list-style-type: none">● Replace the 10 amp METER fuse.● Key ON.● Does fuse fail again?	Yes No	► GO to A3. ► GO to A4.														
A3	CHECK FOR SHORTS TO GROUND																
	<ul style="list-style-type: none">● Locate and disconnect the interior fuse panel connector and instrument cluster connector.● Measure resistance between BK / Y wire at the interior fuse panel connector and ground.● Is resistance less than 5 ohms?	Yes No	► SERVICE BK / Y wire. ► GO to A4.														
A4	CHECK POWER SUPPLY TO TACHOMETER																
	<ul style="list-style-type: none">● Key ON.● Locate the instrument cluster connector.● Measure voltage on the BK / Y wire at the instrument cluster connector.● Is voltage greater than 10 volts?	Yes No	► GO to A5. ► SERVICE BK / Y wire.														
A5	PERFORM TACHOMETER PULSE CHECK NO. 1																
	<ul style="list-style-type: none">● Key OFF.● Locate the ignition coil.● Disconnect the ignition coil connector.● Using a test lead apply 12 volts to the Y / BL wire at the ignition coil connector.● Does the tachometer needle jump?	Yes No	► GO to A8. ► GO to A6.														
A6	PERFORM TACHOMETER PULSE CHECK NO. 2																
	<ul style="list-style-type: none">● Locate the instrument cluster connector.● Key ON.● Using a test lead, apply 12 volts to the Y / BL wire at the instrument cluster connector.● Does the tachometer needle jump?	Yes No	► SERVICE the Y / BL wire between the instrument cluster and ignition coil. ► REPLACE the tachometer.														
A7	CHECK TACHOMETER																
	<ul style="list-style-type: none">● Disconnect Y / BL wire from the ignition coil and place a signal generator and a tachometer tester between the Y / BL wire and ground● Compare the tester and tachometer indications.● Are the readings within allowable range?	Yes No	► REFER to Section 03-07. ► REPLACE the tachometer (See Caution). CAUTION: When removing or installing a tachometer, do not drop or subject it to sharp impact.														
<table><tr><th>Standard Indication (RPM)</th><th>Allowable Range (RPM)</th></tr><tr><td>1000</td><td>100-1050</td></tr><tr><td>2000</td><td>2000-2050</td></tr><tr><td>3000</td><td>3000-3050</td></tr><tr><td>4000</td><td>4000-4050</td></tr><tr><td>5000</td><td>5000-5050</td></tr><tr><td>6000</td><td>6000-6050</td></tr></table>		Standard Indication (RPM)	Allowable Range (RPM)	1000	100-1050	2000	2000-2050	3000	3000-3050	4000	4000-4050	5000	5000-5050	6000	6000-6050		
Standard Indication (RPM)	Allowable Range (RPM)																
1000	100-1050																
2000	2000-2050																
3000	3000-3050																
4000	4000-4050																
5000	5000-5050																
6000	6000-6050																

DIAGNOSIS AND TESTING (Continued)


PINPOINT TEST A: TACHOMETER SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
A8	CHECK TACHOMETER GROUND		
	<ul style="list-style-type: none"> Locate and disconnect the instrument cluster connector. Measure the resistance between the BK wire at the instrument cluster connector and ground. Is resistance less than 5 ohms? 	Yes No	GO to A9. SERVICE BK wire.
A9	CHECK WIRE BETWEEN TACHOMETER AND IGNITION COIL		
	<ul style="list-style-type: none"> Key OFF. Measure resistance of the Y/BL wire between the instrument cluster (tachometer) and ignition coil. Is resistance less than 5 ohms? 	Yes No	RETURN to condition chart. SERVICE Y/BL wire.

Electrical Schematic — Oil Pressure Gauge System




K18637-A



INSTRUMENT CLUSTER K18632-A

Pin Number	Wire Color	Circuit Function
1A	BK	Ground
1B	GN/W	RH Turn Indicator
1C	BR/Y	Transaxle Control Module (TCM) (ATX Only)
1D	R/W	High Beam Indicator
1E	BK/Y	Warning Indicator Lamp Power
1F	GN/BK	LH Turn Indicator
1G	Y/R	Oil Pressure Sender
1H	R/GN	Dimmer Control Module
1I	BK	Ground
1J	BK	Ground
1K	—	Not Used
1L	Y/W	Temperature Gauge Sending Unit

DIAGNOSIS AND TESTING (Continued)



INSTRUMENT CLUSTER

L8225-A

Pin Number	Wire Color	Circuit Function
2A	GN/R	Vehicle Speed Sensor (VSS)
2B	Y/BK	Air Bag Diagnostic Module Indicator
2C	BK	Ground (Vehicle Speed Sensor)
2D	BK/Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN/O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used
2H	BK/Y	Gauge Power
2I	Y/BL	Ignition Coil (Tachometer Pulse)
2J	BK/GN	Ground (Voltage Gauge, Tachometer)

TL8225A

System Inspection— Oil Pressure Gauge System

1. Visually inspect the components of the oil pressure gauge system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged oil pressure gauge 	<ul style="list-style-type: none"> • Blown fuse: <ul style="list-style-type: none"> — 10 amp METER • Damage to wiring harness • Loose or corroded connections

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. Inspect the oil pressure gauge and the oil pressure sender for obvious opens or shorts causing partial operation.
4. If fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART—OIL PRESSURE GAUGE SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> • Oil Pressure Gauge Always Reads Low 	<ul style="list-style-type: none"> • Fuse. • Circuit. • Damaged oil pressure sender. • Damaged oil pressure gauge. 	<ul style="list-style-type: none"> • Go to B1.
<ul style="list-style-type: none"> • Oil Pressure Gauge Always Reads High 	<ul style="list-style-type: none"> • Oil pressure gauge wire shorted to ground. • Damaged oil pressure sender. • Damaged oil pressure gauge. 	<ul style="list-style-type: none"> • Go to B7.
<ul style="list-style-type: none"> • Oil Pressure Gauge Reads Inaccurately 	<ul style="list-style-type: none"> • Damaged oil pressure gauge. • Damaged oil pressure sender. 	<ul style="list-style-type: none"> • Go to B10.

PINPOINT TEST B: OIL PRESSURE GAUGE SYSTEM

TEST STEP	RESULT	ACTION TO TAKE
B1 CHECK FUSE		
<ul style="list-style-type: none"> • Locate the interior fuse panel. • Check the 10 amp METER fuse. • Is fuse OK? 	Yes	GO to B4.
	No	GO to B2.
B2 CHECK SYSTEM		
<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Key ON, engine running. • Does fuse fall again? 	Yes	GO to B3.
	No	GO to B4.


DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B: OIL PRESSURE GAUGE SYSTEM (Continued)



TEST STEP		RESULT	ACTION TO TAKE
B3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> Locate and disconnect the interior fuse panel connector and instrument cluster connector. Measure the resistance between the BK/Y wire at the interior fuse panel connector and ground. Is resistance less than 5 ohms? 	Yes No	SERVICE BK/Y wire. GO to B4.
B4	CHECK POWER SUPPLY TO THE OIL PRESSURE GAUGE		
	<ul style="list-style-type: none"> Locate the instrument cluster connector. Key ON. Measure voltage on the BK/Y wire at the instrument cluster connector. Is voltage greater than 10 volts? 	Yes No	GO to B5. SERVICE BK/Y wire.
B5	CHECK OIL PRESSURE GAUGE		
	<ul style="list-style-type: none"> Key ON. Place a jumper wire from the Y/R wire at instrument cluster connector to ground. Does the oil pressure gauge read high? 	Yes No	GO to B6. REPLACE oil pressure gauge.
B6	CHECK OIL PRESSURE GAUGE WIRE CONTINUITY		
	<ul style="list-style-type: none"> Disconnect oil pressure sender connector. Key ON. Place a jumper wire from Y/R wire at the oil pressure sender connector to ground. Does the oil pressure gauge read high? 	Yes No	GO to B7. SERVICE Y/R wire between oil pressure sender and instrument cluster.
B7	CHECK OIL PRESSURE SENDER		
	<ul style="list-style-type: none"> Disconnect the oil pressure sender. Key ON. Does oil pressure gauge read low? 	Yes No	GO to B8. REPLACE oil pressure sender.
B8	CHECK OIL PRESSURE SENDER		
	<ul style="list-style-type: none"> Locate and disconnect the instrument cluster connector. Key ON. Does oil pressure gauge still read low? 	Yes No	REPLACE oil pressure sender. GO to B9.
B9	CHECK OIL PRESSURE GAUGE GROUND		
	<ul style="list-style-type: none"> Disconnect instrument cluster connector. Measure resistance between the BK wire at the instrument cluster connector and ground. Is the resistance less than 5 ohms? 	Yes No	GO to B10 SERVICE BK wire.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B: OIL PRESSURE GAUGE SYSTEM (Continued)

TEST STEP	RESULT	ACTION TO TAKE
B10 CHECK OIL PRESSURE GAUGE <ul style="list-style-type: none"> • Disconnect oil pressure sender connector. • Connect one lead of Rotunda Gauge System Tester 021-00038 or equivalent to the Y/R wire at the oil pressure connector and the other lead to ground. • Set the tester to resistance values shown. • Place the ignition switch to the ON position and check to see that the needle indicator displays the correct values. • Continue each inspection for two minutes to correctly judge the condition (allowable readings are twice the width of the needle). • Are readings within the allowable range?  <p style="text-align: right;">K19338-A</p>	Yes No	▶ REPLACE oil pressure sender. ▶ REPLACE oil pressure gauge.

Electrical Schematic—Temperature Gauge System



INSTRUMENT CLUSTER


K18632-A

Pin Number	Wire Color	Circuit Function
1A	BK	Ground
1B	GN/W	RH Turn Indicator
1C	BR/Y	Transaxle Control Module (TCM) (ATX Only)
1D	R/W	High Beam Indicator
1E	BK/Y	Warning Indicator Lamp Power
1F	GN/BK	LH Turn Indicator

(Continued)

DIAGNOSIS AND TESTING (Continued)

Pin Number	Wire Color	Circuit Function
1G	Y/R	Oil Pressure Sender
1H	R/GN	Dimmer Control Module
1I	BK	Ground
1J	BK	Ground
1K	—	Not Used
1L	Y/W	Temperature Gauge Sending Unit



INSTRUMENT CLUSTER

L8225-A

Pin Number	Wire Color	Circuit Function
2A	GN/R	Vehicle Speed Sensor (VSS)
2B	Y/BK	Air Bag Diagnostic Module Indicator
2C	BK	Ground (Vehicle Speed Sensor)
2D	BK/Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN/O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used
2H	BK/Y	Gauge Power
2I	Y/BL	Ignition Coil (Tachometer Pulse)
2J	BK/GN	Ground (Voltage Gauge, Tachometer)

TL8225A

System Inspection—Temperature Gauge System

1. Visually inspect the components of the temperature gauge system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged temperature gauge 	<ul style="list-style-type: none"> • Blown fuse: <ul style="list-style-type: none"> — 10 amp METER • Damage to wiring harness • Loose or corroded connections

2. Inspect the temperature gauge for obvious opens or shorts causing partial operation.
3. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
4. If fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART—TEMPERATURE GAUGE SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> • Temperature Gauge Always Reads Cold 	<ul style="list-style-type: none"> • Fuse. • Circuit. • Temperature gauge sending unit. • Temperature gauge. 	<ul style="list-style-type: none"> • Go to C1.
<ul style="list-style-type: none"> • Temperature Gauge Always Reads Hot 	<ul style="list-style-type: none"> • Short to ground. • Temperature gauge sending unit. • Temperature gauge. 	<ul style="list-style-type: none"> • Go to C7.
<ul style="list-style-type: none"> • Temperature Gauge Inaccurate 	<ul style="list-style-type: none"> • Open wires. • Temperature gauge sending unit. 	<ul style="list-style-type: none"> • Go to C10.



DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST C: TEMPERATURE GAUGE SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
C1	CHECK FUSE		
	<ul style="list-style-type: none"> Locate the interior fuse panel. Check 10 amp METER fuse. Is fuse OK? 	Yes No	GO to C4. GO to C2.
C2	CHECK SYSTEM		
	<ul style="list-style-type: none"> Replace the 10 amp METER fuse. Key ON. Does fuse fail again? 	Yes No	GO to C3. GO to C4.
C3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> Locate and disconnect the interior fuse panel connector and instrument cluster connector. Measure resistance between BK/Y wire at the interior fuse panel connector and ground. Is resistance less than 5 ohms? 	Yes No	SERVICE BK/Y wire. GO to C4.
C4	CHECK POWER SUPPLY TO TEMPERATURE GAUGE		
	<ul style="list-style-type: none"> Key ON. Locate instrument cluster connector. Measure voltage on the BK/Y wire at the instrument cluster connector. Is voltage greater than 10 volts? 	Yes No	GO to C5. SERVICE BK/Y wire.
C5	CHECK TEMPERATURE GAUGE		
	<ul style="list-style-type: none"> Locate instrument cluster connector. Key ON. Place a jumper wire from the Y/W wire at instrument cluster to ground. Does temperature gauge read hot? 	Yes No	GO to C6. REPLACE temperature gauge.
C6	CHECK TEMPERATURE GAUGE WIRE CONTINUITY		
	<ul style="list-style-type: none"> Key ON. Place a jumper wire from Y/W wire at the temperature gauge sending unit to ground. Does the temperature gauge read hot? 	Yes No	GO to C7. SERVICE Y/W wire between the temperature gauge sending unit and instrument cluster.
C7	CHECK TEMPERATURE GAUGE		
	<ul style="list-style-type: none"> Disconnect the temperature gauge sending unit. Does temperature gauge read cold? 	Yes No	GO to C8. REPLACE temperature gauge.
C8	CHECK TEMPERATURE GAUGE		
	<ul style="list-style-type: none"> Locate and disconnect the instrument cluster connector. Does the temperature gauge still read cold? 	Yes No	REPLACE temperature gauge. GO to C9.
C9	CHECK TEMPERATURE GAUGE GROUND		
	<ul style="list-style-type: none"> Locate and disconnect instrument cluster connector. Measure resistance between the BK wire at the instrument cluster connector and ground. Is resistance less than 5 ohms? 	Yes No	GO to C10. SERVICE BK wire.


DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST C: TEMPERATURE GAUGE SYSTEM (Continued)


TEST STEP	RESULT	ACTION TO TAKE
<p>C10 CHECK TEMPERATURE GAUGE SENDING UNIT</p> <ul style="list-style-type: none"> Remove connector from temperature gauge sending unit. Connect one lead of the Rotunda Gauge System Tester 021-00055 or equivalent to the connector and the other lead to ground. Set gauge tester to the resistance values shown. Place ignition switch to the ON position and check to see that the needle indicator displays the correct reading. Continue each inspection for two minutes to correctly judge the condition (allowable readings are twice the width of the needle). Are readings within the allowable range?  <p>K17161-A</p>  <p>K17160-B</p>	<p>Yes</p> <p>No</p>	<p>▶ GO to C11.</p> <p>▶ REPLACE temperature gauge sending unit.</p>
<p>C11 CHECK TEMPERATURE GAUGE SENDING UNIT</p> <ul style="list-style-type: none"> Remove temperature gauge sending unit. Place temperature gauge sending unit in a container of water and heat to 80°C (176°F). Measure resistance between the case and the terminal of the sending unit. Does resistance measure between 49.3 ohms and 57.7 ohms? 	<p>Yes</p> <p>No</p>	<p>▶ GO to C12.</p> <p>▶ REPLACE temperature gauge sending unit.</p>
<p>C12 CHECK TEMPERATURE GAUGE SENDING UNIT</p> <ul style="list-style-type: none"> Key OFF. Measure resistance between temperature gauge sending unit casing and ground. Is resistance less than 5 ohms? 	<p>Yes</p> <p>No</p>	<p>▶ RETURN to condition chart.</p> <p>▶ REPLACE temperature gauge sending unit.</p>

DIAGNOSIS AND TESTING (Continued)

Electrical Schematic—Turbo Boost Gauge System



K18639-A



INSTRUMENT CLUSTER


L8225-A

Pin Number	Wire Color	Circuit Function
2A	GN/R	Vehicle Speed Sensor (VSS)
2B	Y/BK	Air Bag Diagnostic Module Indicator
2C	BK	Ground (Vehicle Speed Sensor)

(Continued)

Pin Number	Wire Color	Circuit Function
2D	BK/Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN/O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used
2H	BK/Y	Gauge Power
2I	Y/BL	Ignition Coil (Tachometer Pulse)
2J	BK/GN	Ground (Voltage Gauge, Tachometer)

TL8225A



K18640-A

Pin Number	Wire Color	Circuit Function
3A	BR/W	Parking Brake Switch
3B	W/BL	Boost Sensor
3C	LG/R	Powertrain Control Module (PCM)
3D	BK	Boost Sensor
3E	—	Not Used
3F	Y	Fuel Gauge Sending Unit
3G	W/BK	Generator
3H	BK/GN	Ground

System Inspection—Turbo Boost Gauge System

1. Visually inspect the components of the turbo boost gauge system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged turbo boost gauge 	<ul style="list-style-type: none"> • Blown fuse: <ul style="list-style-type: none"> — 10 amp METER • Damage to wiring harness • Loose or corroded connections

DIAGNOSIS AND TESTING (Continued)

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. Inspect the turbo boost gauge and the boost sensor for obvious opens or shorts causing partial operation.
4. If fault is not visually evident, determine condition and refer to the following condition chart.

CONDITION CHART — TURBO BOOST GAUGE SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
• Turbo Boost Gauge Always Reads Low	<ul style="list-style-type: none"> • Fuse. • Circuit. • Damaged boost sensor. • Damaged turbo boost gauge. 	• Go to D1.
• Turbo Boost Gauge Always Reads High	<ul style="list-style-type: none"> • Circuit. • Damaged boost sensor. • Damaged turbo boost gauge. 	• Go to D4.
• Turbo Boost Gauge Is Erratic	<ul style="list-style-type: none"> • Damaged boost sensor. • Damaged turbo boost gauge. 	• Go to D4.

PINPOINT TEST D: TURBO BOOST GAUGE SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
D1	CHECK FUSE		
	<ul style="list-style-type: none"> • Locate the interior fuse panel. • Check the 10 amp METER fuse. • Is fuse OK? 	Yes No	► GO to D4. ► GO to D2.
D2	CHECK SYSTEM		
	<ul style="list-style-type: none"> • Replace the 10 amp METER fuse. • Key ON. • Does fuse fall again? 	Yes No	► GO to D3. ► GO to D4.
D3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> • Locate and disconnect the interior fuse panel connector and instrument cluster connector. • Measure resistance between BK/Y at the interior fuse panel and ground. • Is resistance less than 5 ohms? 	Yes No	► SERVICE the BK/Y wire. ► GO to D4.
D4	CHECK POWER SUPPLY TO TURBO BOOST GAUGE		
	<ul style="list-style-type: none"> • Locate and disconnect the instrument cluster connector. • Key ON. • Measure voltage on the BK/Y wire at the instrument cluster connector. • Is voltage greater than 10 volts? 	Yes No	► GO to D5. ► SERVICE BK/Y wire.
D5	CHECK GROUND WIRES		
	<ul style="list-style-type: none"> • Locate and disconnect the instrument cluster 8 pin connector and the boost sensor connector. • Measure the resistance between the BK wire between the instrument cluster connector and boost sensor connector. • Is resistance less than 5 ohms? 	Yes No	► GO to D6. ► SERVICE BK wire.
D6	CHECK VOLTAGE AT BOOST SENSOR		
	<ul style="list-style-type: none"> • Locate and disconnect boost sensor connector. • Key ON. • Measure voltage on the Y/GN wire at the boost sensor connector. • Is the voltage greater than 10 volts? 	Yes No	► GO to D7. ► SERVICE Y/GN wire.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST D: TURBO BOOST GAUGE SYSTEM (Continued)


TEST STEP		RESULT	ACTION TO TAKE
D7	CHECK BOOST GAUGE SIGNAL WIRE		
	<ul style="list-style-type: none"> Locate and disconnect instrument cluster 8-pin connector. Disconnect boost sensor. Measure resistance of the W / BL wire between the instrument cluster connector and boost sensor connector. Is resistance less than 5 ohms? 	Yes No	GO to D8. SERVICE W / BL wire.
D8	CHECK TURBO BOOST GAUGE		
	<ul style="list-style-type: none"> Locate the instrument cluster 8 pin connector. Key ON. Ground W / BL wire at the turbo boost gauge (instrument cluster connector). Does the turbo boost gauge read low? Apply 12 volts to W / BL wire at the turbo boost gauge (instrument cluster connector). Does turbo boost gauge read high? 	Yes No	GO to D9. REPLACE turbo boost gauge.
D9	CHECK BOOST SENSOR		
	<ul style="list-style-type: none"> Disconnect boost sensor connector. Place a jumper wire between Y / GN and W / BL wires on boost sensor connector. Key ON. Does turbo boost gauge read high? 	Yes No	REPLACE boost sensor. RETURN to condition chart.

REMOVAL AND INSTALLATION

Tachometer

Removal

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.
3. Separate speedometer / tachometer / boost gauge assembly from other gauge assemblies.



K12933-A

Installation

CAUTION: Tachometer is calibrated at the factory. Excessive rough handling could disturb calibration.

1. Position speedometer / tachometer / boost gauge assembly to other gauge assemblies.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check tachometer and all other gauges / indicators for proper operation.


Temperature Gauge

Removal

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.

REMOVAL AND INSTALLATION (Continued)

3. Separate the temperature / oil pressure gauge from the speedometer / tachometer / boost gauge assembly. (The boost gauge is used only on turbocharged vehicles.)



K14781-A

Installation

CAUTION: The gauges are calibrated at the factory. Excessive rough handling could disturb calibration.


1. Position temperature / oil pressure gauge to speedometer / tachometer / boost gauge assembly.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check all gauges and indicators for proper operation.

Temperature Sending Unit**Removal**

1. Relieve cooling system pressure.

WARNING: NEVER REMOVE THE RADIATOR CAP UNDER ANY CIRCUMSTANCES WHILE THE ENGINE IS OPERATING. FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN SERIOUS PERSONAL INJURY FROM HOT COOLANT OR STEAM BLOW OUT (AND/OR DAMAGE TO THE COOLING SYSTEM OR ENGINE). SWITCH OFF THE ENGINE AND WAIT UNTIL IT HAS COOLED. EVEN THEN, USE EXTREME CARE WHEN REMOVING THE CAP FROM A HOT RADIATOR. WRAP A THICK CLOTH AROUND THE CAP AND TURN IT SLOWLY TO THE FIRST STOP. STEP BACK WHILE THE PRESSURE IS RELEASED FROM THE COOLING SYSTEM. WHEN CERTAIN ALL THE PRESSURE HAS BEEN RELEASED, PRESS DOWN ON THE CAP WITH A CLOTH, TURN AND REMOVE IT.

2. Partially drain engine coolant. Refer to Section 03-03.
3. Disconnect electrical connector from sending unit.
4. Using a suitable tool, unscrew sending unit.




K15019-A

Installation

1. Apply Pipe Sealant with Teflon® D8AZ-19554-A (ESG-M4G194-A or ESR-M18P7-A), or equivalent to threads of sending unit.
2. Install sending unit into cylinder head. Tighten securely.
3. Connect electrical connector onto sending unit terminal.
4. Fill cooling system to proper level. Refer to Section 03-03.
5. Check gauge for proper operation.

REMOVAL AND INSTALLATION (Continued)**Oil Pressure Gauge****Removal**

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.
3. Separate the temperature / oil pressure gauge from the speedometer / tachometer / boost gauge assembly. (The boost gauge is used only on turbocharged vehicles.)

**Installation**

CAUTION: The gauges are calibrated at the factory. Excessive rough handling could disturb calibration.


1. Position temperature / oil pressure gauge to speedometer / tachometer / boost gauge assembly.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check all gauges and indicators for proper operation.

Oil Pressure Sending Unit**Removal**

1. Disconnect electrical lead wire from oil sending unit.

CAUTION: Do not use locking-type pliers to remove or install oil sending unit. The diaphragm in the sending unit could be damaged with the use of locking-type pliers.

2. Unscrew oil sending unit with a suitable tool.

**Installation**


1. Apply pipe sealant with Teflon® D8AZ-19554-A (ESG-M4G 194-A or ESR-M18P7-A) or equivalent to threads of sending unit.
2. Install sending unit into cylinder head. Tighten to 16-23 N·m (12-16 lb-ft).
3. Connect electrical lead onto sending unit terminal.

Turbo Boost Gauge**Removal**

1. Disconnect negative battery cable.
2. Remove and disassemble instrument cluster assembly. Refer to Section 13-01.

REMOVAL AND INSTALLATION (Continued)

3. Separate speedometer / tachometer / boost gauge assembly from other gauge assemblies.



K14784-A

Installation

CAUTION: Gauges are calibrated at the factory. Excessive rough handling could disturb calibration.


1. Position speedometer, tachometer, and boost gauge assembly to other gauge assemblies.
2. Install gauge assembly into instrument cluster and install cluster. Refer to Section 13-01.
3. Connect negative battery cable.
4. Check all gauges and indicators for proper operation.

Turbo Boost Gauge Sensor

Removal

1. Disconnect vacuum line and electrical connector from sensor.

2. Remove two nuts and washers.
3. Remove sensor.



K14785-B

Installation

1. Install sensor with two washers and nuts. Tighten to 6-10 N·m (5-7 lb-ft).
2. Inspect vacuum lines and replace as required.
3. Connect vacuum line and electrical connector to sensor.
4. Check all gauges for proper operation.

SPECIFICATIONS

TORQUE SPECIFICATIONS

Description	N·m	Lb·Ft
Oil Pressure Sending Unit	16-23	12-16
Turbo Boost Gauge Sensor	6-10	5-7

SECTION 13-06 Horn

SUBJECT	PAGE	SUBJECT	PAGE
ADJUSTMENTS	13-06-4	REMOVAL AND INSTALLATION	
DESCRIPTION	13-06-1	Horn Relay	13-06-5
DIAGNOSIS AND TESTING		Horn Switch	13-06-4
Electrical Schematic—Horn System	13-06-2	Horns and Brackets	13-06-4
System Inspection—Horn System	13-06-2	SPECIFICATIONS	13-06-5
		VEHICLE APPLICATION	13-06-1

VEHICLE APPLICATION

Capri.


DESCRIPTION

The horns are mounted above the left fog lamp, behind the front bumper. The horn switches are located in the upper steering wheel spokes and are actuated by pushing on either horn symbol switches.

The horn relay is mounted on the left inner headlamp support.

DIAGNOSIS AND TESTING

Electrical Schematic—Horn System



System Inspection—Horn System

1. Visually inspect components of the horn system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged Horn Switch • Damaged Horn Unit • Damaged Relay 	<ul style="list-style-type: none"> • Blown Fuse: <ul style="list-style-type: none"> • 20 amp STOP fuse • Damaged Wire Harnesses • Loose or Corroded Connections

2. Operate horn switch and observe high and low horn operation.
3. Briefly inspect the exposed wiring harnesses and connectors for apparent damage.
4. If the fault is not visually evident, determine the condition and refer to the following chart.

DIAGNOSIS AND TESTING (Continued)

CONDITION CHART — HORN SYSTEM

CONDITION	POSSIBLE SOURCE	ACTION
● Horn Does Not Work	<ul style="list-style-type: none"> ● Fuse. ● Horn relay. ● Horn switch. ● Horns. ● Circuit. 	<ul style="list-style-type: none"> ● Go to H1. ● Go to H5. ● Go to H9. ● Go to H8. ● Go to H4.
● Horn Works Continuously	<ul style="list-style-type: none"> ● Short to ground. ● Horn relay. ● Horn switch. ● Horns. ● Circuit. 	<ul style="list-style-type: none"> ● Go to H3. ● Go to H5. ● Go to H9. ● Go to H8. ● Go to H4.
● Horns Work Abnormally	<ul style="list-style-type: none"> ● Short to ground. ● Horn relay. ● Horn switch. ● Horns. ● Circuit. 	<ul style="list-style-type: none"> ● Go to H3. ● Go to H5. ● Go to H9. ● Go to H8. ● Go to H4.

PINPOINT TEST H—HORN SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
H1	CHECK FUSE		
	<ul style="list-style-type: none"> ● Locate interior fuse panel. ● Check the 20 amp STOP fuse. ● Is fuse OK? 	Yes No	► GO to H4. ► GO to H2.
H2	CHECK SYSTEM		
	<ul style="list-style-type: none"> ● Replace the 20 amp STOP fuse. ● Did fuse fail again? 	Yes No	► GO to H3. ► GO to H4.
H3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> ● Disconnect horn relay connector. ● Locate and disconnect the interior fuse panel connector. ● Measure resistance between the GN/Y wire at the interior fuse panel connector and ground. ● Is resistance less than 5 ohms? 	Yes No	► SERVICE GN/Y wire. ► GO to H4.
H4	CHECK POWER SUPPLY TO HORN RELAY		
	<ul style="list-style-type: none"> ● Disconnect the horn relay connector. ● Measure voltage on the GN/Y wire at horn relay connector. ● Is voltage greater than 10 volts? 	Yes No	► GO to H5. ► SERVICE GN/Y wire.
H5	CHECK HORN RELAY		
	<ul style="list-style-type: none"> ● Disconnect horn relay connector. ● Measure resistance between the GN/Y terminal and the GN/R terminal on horn relay. ● Is resistance greater than 10,000 ohms? ● Apply 12 volts to the GN/Y terminal on horn relay. ● Ground the GN/BK terminal on horn relay. ● Measure resistance between the GN/Y terminal and the GN/R terminal. ● Is resistance less than 5 ohms? 	Yes No	► GO to H6. ► REPLACE horn relay.
H6	CHECK WIRE BETWEEN HORN RELAY AND HORNS		
	<ul style="list-style-type: none"> ● Measure resistance of the GN/R wire between the horn relay and the horns. ● Is resistance less than 5 ohms? 	Yes No	► GO to H7. ► SERVICE GN/R wire(s).
H7	CHECK HORNS		
	<ul style="list-style-type: none"> ● Disconnect horn connectors. ● Apply 12 volts to the GN/R terminals on the horns. ● Did horns sound? 	Yes No	► GO to H8. ► SERVICE/REPLACE horns.


DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST H—HORN SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
H8	CHECK WIRE BETWEEN HORN RELAY AND HORN SWITCH		
	<ul style="list-style-type: none"> Locate horn switch. Measure resistance of the GN / BK wire between the horn relay and the horn switch. Is resistance less than 5 ohms? 	Yes No	GO to H9. SERVICE GN / BK wire.
H9	CHECK HORN SWITCH		
	<ul style="list-style-type: none"> Disconnect horn switch connector. Measure resistance between the GN / BK terminal and the BK terminal on the horn switch. Is resistance greater than 10,000 ohms? 	Yes No	RETURN to condition chart. REPLACE horn switch.

ADJUSTMENTS

- Verify that ground is good by checking the connections for corrosion and that the mounting screw is tight.
- Attach a wire to the positive (+) battery terminal and to the horn contact. If the horn sounds normally, check the wiring to the horn. If it does not sound, proceed to Step 3.
- Connect a wire between the negative (-) terminal of the battery and the mounting bracket. Connect another wire from the positive (+) terminal of the battery to the horn contact. If the horn does not sound and there is no evidence of a spark at the battery terminal, turn the adjusting screw one-quarter to three-eighths of a turn. Then secure adjusting screw by clinching housing extrusion with diagonals or pliers. If horn does not function, refer to Diagnosis and Testing.




REMOVAL AND INSTALLATION

Horns and Brackets

Removal

- Disconnect wiring connectors from horn.
- Remove retaining bolts from brackets.
- Remove horn from below bumper.



K13741-A

Installation

- Position horn assembly.
- Install bolts through brackets and into radiator support. Tighten to 7-10 N·m (5-7 lb-ft).
- Attach wiring connector to horn contact.
- Verify proper operation of horns.

Horn Switch

Removal

- Disconnect negative battery cable.
- Remove horn switch by carefully prying around switch bezel with small, flat-bladed screwdriver.
- Disconnect two wires from switch.

Installation


- Connect two wires to switch.
- Install switch in steering wheel.
- Connect negative battery cable and verify proper operation.

REMOVAL AND INSTALLATION (Continued)**Horn Relay****Removal**

1. Locate horn relay on the left inner headlamp support.
2. Disconnect plug at horn relay.
3. Remove screw securing relay to inner headlamp support.

Installation

1. Install screw through relay bracket and into inner fender.
2. Connect plug at horn relay.



K10282-B

SPECIFICATIONS**TORQUE SPECIFICATIONS**

Description	N·m	Lb·Ft
Horn Retaining Bolts	7-10	5-7

SECTION 13-07 Clock

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION	13-07-1	VEHICLE APPLICATION	13-07-1
REMOVAL AND INSTALLATION			
Clock.....	13-07-1		

VEHICLE APPLICATION


Capri.

DESCRIPTION

The quartz movement, electronic clock is mounted on the RH side of the instrument panel bezel. The illumination for the clock is set so that when the headlamps or parking lamps are turned on, the intensity of the clock lamp is lowered and controlled by the instrument panel lighting control. When all the lamps are turned off the intensity is increased for easier viewing in bright sunlight. The clock displays time in a 12 hour format and is always on. Changing the time can be done as follows:

To change the hour digits, press the HOUR button. Pressing the button once and then releasing it advances and sets the digits one at a time. Holding the button in, advances the digits rapidly.

To change the minute digits, press the MIN button. Pressing the button once and releasing it advances and sets the digits one at a time. Holding the button in, advances the digits rapidly.




K12927-A

REMOVAL AND INSTALLATION

Clock

Removal

1. Remove instrument cluster bezel. Refer to Section 01-12.
2. Rotate bulb socket and remove.
3. Remove screws and clock assembly.



K12928-A

REMOVAL AND INSTALLATION (Continued)**Installation**

1. Install clock with screws to instrument cluster bezel.
2. Install bulb socket to clock.

3. Install instrument cluster bezel. Refer to Section 01-12.

SECTION 13-09 Gauges, Warning Devices, Miscellaneous—Analog

SUBJECT	PAGE	SUBJECT	PAGE
DESCRIPTION		DIAGNOSIS AND TESTING (Cont'd.)	
Air Bag Indicator Lamp.....	13-09-2	Electrical Schematic—Warning Indicator	
Brake Indicator.....	13-09-2	Lamps System.....	13-09-5
Charge Warning Indicator Lamp.....	13-09-2	System Inspection—Warning Indicator	
Check Engine Warning Lamp.....	13-09-1	System.....	13-09-8
High Beam Indicator.....	13-09-2	REMOVAL AND INSTALLATION	
Instrument Panel Lamps.....	13-09-1	Brake Fluid Level Switch.....	13-09-19
Safety Belt Indicator.....	13-09-1	High Beam Switch.....	13-09-18
Turn Signal Indicators.....	13-09-2	Parking Brake Switch.....	13-09-18
DIAGNOSIS AND TESTING		Safety Belt Switch.....	13-09-19
Electrical Schematic—Timer/Buzzer Warning		Warning/Indicator Lamp Bulbs.....	13-09-18
System.....	13-09-3	VEHICLE APPLICATION	13-09-1

VEHICLE APPLICATION

Capri.

DESCRIPTION

Instrument Panel Lamps

All instrument panel lamps should illuminate when the ignition switch is turned to the "ON" position except the brake warning indicator lamp. The brake warning indicator lamp should illuminate for a few seconds when the ignition is turned to the "START" position. The illumination of these lamps proves that the bulbs are operating correctly.

Some switches include indicator lamps as part of the switch. These are not serviced separately. The fog lamp switch, headlamp switch, and defogger switch all include indicator lamps.

Safety Belt Indicator

The system incorporates a buzzer and lamp as warning devices. The safety belt warning lamp illuminates for several seconds after the ignition switch is turned to the RUN position, regardless of safety belt usage. The safety belt warning buzzer is grounded by a switch in the left inboard buckle. The safety belt warning buzzer will sound unless the driver's belt is connected.

Check Engine Warning Lamp

The check engine warning lamp illuminates when there is a problem in the engine control or emission system. Refer to the Powertrain Control/Emissions Diagnosis Manual¹ for further information.

¹ Can be purchased as a separate item.

DESCRIPTION (Continued)**Brake Indicator**

The brake indicator illuminates when the parking brake lever is lifted up, a leak in the brake hydraulic system occurs, the brake fluid in the reservoir is low, or too much air is contained in the hydraulic system causing the two separate hydraulic systems to become unbalanced. The ignition switch must be in the RUN position.

The lamp will illuminate when the ignition is turned to the START position and should go out when the engine is started.

The brake indicator circuit consists of the parking brake switch and a pressure differential warning switch.

Air Bag Indicator Lamp

Refer to Section 01-20B for information on the air bag warning indicator lamp.

Turn Signal Indicators

The turn signal system consists of the multi-function switch, turn signal/hazard flasher, indicating lamps and necessary wiring. Refer to Section 11-05 for additional information.

High Beam Indicator


This indicator lamp illuminates when the headlamps are on and in high beam position or when the flash-to-pass switch is activated.

Charge Warning Indicator Lamp



This indicator lamp illuminates if there is a concern in either the generator or wiring systems. Refer to Section 13-01 for additional information.

DIAGNOSIS AND TESTING

Electrical Schematic—Timer / Buzzer Warning System




K18642-A


DIAGNOSIS AND TESTING (Continued)**TIMER/BUZZER MODULE****K18643-A****IGNITION KEY RELAY****K18644-A**

DIAGNOSIS AND TESTING (Continued)

Electrical Schematic — Warning Indicator Lamps System




DIAGNOSIS AND TESTING (Continued)




AIR BAG DIAGNOSTIC MODULE K18646-A

Pin Number	Wire Color	Circuit Function
A	PK/W	Center Crash Sensor
B	P/O	Air Bag Diagnostic Module Power Supply
C	PK/O	RH Crash Sensor
D	BK	Ground
E	BL/W	Safing Sensor Ground
F	Y/BK	Air Bag Indicator Lamp
G	W/O	Safing Sensor
H	BK	Ground
I	BL/O	Air Bag Backup Power Supply
J	BK	Ground
K	BL	Battery Power Supply
L	P/O	Air Bag Diagnostic Module Power Supply




TIMER/BUZZER MODULE K18647-A



INSTRUMENT CLUSTER K18632-A

Pin Number	Wire Color	Circuit Function
1A	BK	Ground
1B	GN/W	RH Turn Indicator
1C	BR/Y	Transaxle Control Module (TCM) (Auto Only)
1D	R/W	High Beam Indicator
1E	BK/Y	Warning Indicator Lamp Power
1F	GN/BK	LH Turn Indicator
1G	Y/R	Oil Pressure Sender
1H	R/GN	Dimmer Control Module
1I	BK	Ground
1J	BK	Ground
1K	—	Not Used
1L	Y/W	Temperature Gauge Sending Unit




INSTRUMENT CLUSTER L8225-A

Pin Number	Wire Color	Circuit Function
2A	GN/R	Vehicle Speed Sensor (VSS)
2B	Y/BK	Air Bag Diagnostic Module Indicator

(Continued)


DIAGNOSIS AND TESTING (Continued)

Pin Number	Wire Color	Circuit Function
2C	BK	Ground for VSS
2D	BK/Y	Safety Belt Warning Indicator Lamp Power
2E	BK	Ground
2F	GN/O	Safety Belt Warning Indicator Lamp Ground
2G	—	Not Used
2H	BK/Y	Gauge Power
2I	Y/BL	Ignition Coil
2J	BK/GN	Ground for Voltmeter, Tach and Boost



K18640-A

Pin Number	Wire Color	Circuit Function
3A	BR/W	Parking Brake Switch
3B	W/BL	Boost Sensor
3C	LG/R	Powertrain Control Module (PCM)
3D	BK	Boost Sensor
3E	—	Not Used
3F	Y	Fuel Gauge Sending Unit
3G	W/BK	Generator
3H	BK/GN	Ground


POWERTRAIN
CONTROL
MODULE

Q3240-A

Pin Number	Wire Color	Circuit Function
1A	LG/R	MIL Lamp
1B	GN/BK	Self Test Output
1C	—	Not Used
1D	BK/BL	Switch Monitor Lamp
1E	GN/O	Idle Switch
1F	W	WAC Relay
1G	R/BL	Park/Neutral Position Switch, Clutch Pedal Position Switch
1H	—	Not Used
1I	BL	Electrical Load Control Module
1J	W/GN	Brake On/Off (BOO) Switch
1K	GN/R	Power Steering Pressure Switch
1L	R	A/C Control Switch
1M	Y/BL	Ignition Diagnostic Monitor
1N	Y	Cylinder Identification Sensor
1O	—	Not Used
1P	—	Not Used
1Q	—	Not Used
1R	—	Not Used
1S	—	Not Used
1T	—	Not Used
1U	LG/Y	Ignition Control Module (Non-Turbo) Knock Control Unit 1 (Turbo)
1V	BK	Ground (Non-Turbo Only)
1W	Y	Self Test Input
1X	—	Not Used


TQ3240A

DIAGNOSIS AND TESTING (Continued)



TRANSAXLE CONTROL MODULE (TCM)
K18648-A

Pin Number	Wire Color	Circuit Function
1A	—	Not Used
1B	BR / Y	Manual Shift Lamp
1C	R	STO Test Connector
1D	—	Not Used
1E	R / BK	STI Test Connector
1F	W / GN	Brake On / Off (BOO) Switch
1G	—	Not Used
1H	BR / BK	Manual Shift Switch
1I	—	Not Used
1J	BK	Ground
1K	—	Not Used
1L	—	Not Used
1M	BK / BL	Transaxle Oil Temperature Switch
1N	BL / GN	Powertrain Control Module (PCM)
1O	GN / O	Powertrain Control Module (PCM)
1P	GN / R	Vehicle Speed Sensor (VSS)




COMBINATION SWITCH
K19278-A

Pin Number	Wire Color	Circuit Function
1A	R / GN	Headlamp Switch
1B	R / BK	Low Beam Power Supply

(Continued)

Pin Number	Wire Color	Circuit Function
1C	R / W	High Beam Power Supply
1D	R	Power Supply
1E	GN / BK	Left Turn Signal
1F	—	Not Used
1G	GN / BK	Left Turn Signal



COMBINATION SWITCH

K19279-A

Pin Number	Wire Color	Circuit Function
2A	GN / W	Right Turn Signal
2B	GN / W	Right Turn Signal
2C	GN / Y	Flasher Module
2D	—	Not Used
2E	GN / R	Hazard Flasher
2F	—	Not Used

System Inspection—Warning Indicator System

1. Visually inspect the components of the warning system.

VISUAL INSPECTION CHART

Mechanical	Electrical
<ul style="list-style-type: none"> • Damaged components 	<ul style="list-style-type: none"> • Blown Fuses: <ul style="list-style-type: none"> • 10 amp ROOM • 10 amp METER • Damage to wiring harness • Loose or corroded connections

2. Check the wiring harness for obvious signs of shorts, opens, bad connections or damage.
3. If the fault is not visually evident, determine condition and refer to the following condition chart.

DIAGNOSIS AND TESTING (Continued)

CONDITION CHART—WARNING INDICATORS

CONDITION	POSSIBLE SOURCE	ACTION
<ul style="list-style-type: none"> Timer / Buzzer Not Operating Correctly 	<ul style="list-style-type: none"> Fuse(s). Switches. Circuit. Timer / buzzer module 	<ul style="list-style-type: none"> Go to A1.
<ul style="list-style-type: none"> Buzzer Not Operating With Key in the Ignition 	<ul style="list-style-type: none"> Timer / buzzer module. Circuit. Ignition key relay. 	<ul style="list-style-type: none"> Go to A10.
<ul style="list-style-type: none"> Buzzer Not Operating With the Doors Open 	<ul style="list-style-type: none"> Door courtesy lamp switches. Circuit Ignition key relay. 	<ul style="list-style-type: none"> Go to A21.
<ul style="list-style-type: none"> Buzzer Not Operating With the Safety Belts Not Connected 	<ul style="list-style-type: none"> Safety belt switch. Circuit. Timer / buzzer module. 	<ul style="list-style-type: none"> Go to A33.
<ul style="list-style-type: none"> No Buzzer With Safety Belt Illumination Indicator On 	<ul style="list-style-type: none"> Circuit. Timer / buzzer module. 	<ul style="list-style-type: none"> Go to A19.
<ul style="list-style-type: none"> Buzzer Constantly Operating With the Key in the Ignition 	<ul style="list-style-type: none"> Door courtesy lamp switches. Circuit. Timer / buzzer module. 	<ul style="list-style-type: none"> Go to A25.
<ul style="list-style-type: none"> All Warning Indicators Not Operating Correctly 	<ul style="list-style-type: none"> Fuse. Bulbs. Circuit. Instrument cluster circuit board. 	<ul style="list-style-type: none"> Go to B1.
<ul style="list-style-type: none"> Some Warning Indicators Not On 	<ul style="list-style-type: none"> Bulb(s). Circuit. Instrument cluster circuit board. 	<ul style="list-style-type: none"> Go to B1.
<ul style="list-style-type: none"> Combination Switch in the LH Turn Position, Indicator Not On 	<ul style="list-style-type: none"> Circuit. Instrument cluster circuit board. Bulb. 	<ul style="list-style-type: none"> Go to B24.
<ul style="list-style-type: none"> Combination Switch in the RH Turn Position, Indicator Not On 	<ul style="list-style-type: none"> Circuit. Instrument cluster circuit board. Bulb. 	<ul style="list-style-type: none"> Go to B33.
<ul style="list-style-type: none"> Combination Switch in the High Beam Position, Indicator Not On 	<ul style="list-style-type: none"> Circuit. Instrument cluster circuit board. Bulb. 	<ul style="list-style-type: none"> Go to B37.

PINPOINT TEST A—TIMER/BUZZER WARNING SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
A1	CHECK FUSE		
	<ul style="list-style-type: none"> Locate the interior fuse panel. Check 10 amp ROOM fuse. Is fuse OK? 	Yes No	► GO to A4 . ► GO to A2 .
A2	CHECK SYSTEM		
	<ul style="list-style-type: none"> Replace 10 amp ROOM fuse. Does fuse fail again? 	Yes No	► GO to A3 . ► GO to A4 .
A3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> Locate and disconnect interior fuse panel connector. Disconnect the ignition key relay and timer / buzzer module. Measure resistance between the BL / R wire at the interior fuse panel connector and ground. Is resistance less than 5 ohms? 	Yes No	► SERVICE the BL / R wire(s). ► GO to A4 .
A4	CHECK POWER SUPPLY TO IGNITION KEY RELAY		
	<ul style="list-style-type: none"> Locate the ignition key relay. Measure voltage on the BL / R wire at the ignition key relay. Is voltage greater than 10 volts? 	Yes No	► GO to A5 . ► SERVICE BL / R wire.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—TIMER/BUZZER WARNING SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
A5	CHECK IGNITION KEY RELAY		
	<ul style="list-style-type: none"> Disconnect ignition key connector. Measure resistance between the BL / BK and BK / BL terminals on the relay. Is resistance greater than 10,000 ohms? 	Yes No	GO to A6. REPLACE ignition key relay.
A6	CHECK OPERATION OF IGNITION KEY RELAY		
	<ul style="list-style-type: none"> Disconnect the ignition key relay. Apply 12 volts to the BL / R terminal on the ignition key relay. Ground R / Y terminal on the ignition key relay. Measure resistance between the BL / BK and BK / BL terminals on the ignition key relay. Is resistance less than 5 ohms? 	Yes No	GO to A7. REPLACE ignition key relay.
A7	CHECK IGNITION KEY REMINDER SWITCH OPERATION		
	<ul style="list-style-type: none"> Disconnect ignition key relay. Measure resistance from the BK / BL wire at the ignition key relay connector to ground. Key in ignition—Less than 5 ohms Key removed from ignition—Greater than 10,000 ohms Are resistance(s) correct? 	Yes No	GO to A9. GO to A8.
A8	CHECK WIRE TO IGNITION KEY REMINDER SWITCH		
	<ul style="list-style-type: none"> Disconnect ignition key relay and ignition key reminder switch. Measure resistance of the BK / BL wire between the ignition key relay and the ignition key reminder switch. Is resistance less than 5 ohms? 	Yes No	REPLACE ignition key reminder switch. SERVICE BK / BL wire.
A9	CHECK FUSE		
	<ul style="list-style-type: none"> Locate the interior fuse panel. Check 10 amp METER fuse. Is fuse OK? 	Yes No	GO to A12. GO to A10.
A10	CHECK SYSTEM		
	<ul style="list-style-type: none"> Replace 10 amp METER fuse. Key ON Does fuse fail again? 	Yes No	GO to A11. GO to A12.
A11	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> Locate and disconnect interior fuse panel connector. Disconnect timer / buzzer module connector. Measure resistance between the BK / Y wire at the interior fuse panel connector and ground. Is resistance less than 5 ohms? 	Yes No	SERVICE BK / Y wire from the interior fuse panel to timer / buzzer module. GO to A12.
A12	CHECK WIRE FROM INSTRUMENT CLUSTER TO TIMER / BUZZER MODULE		
	<ul style="list-style-type: none"> Locate instrument cluster 10-pin connector. Measure resistance of the GN / O wire between the instrument cluster and timer / buzzer module. Is resistance less than 5 ohms? 	Yes No	GO to A13. SERVICE GN / O wire.
A13	CHECK POWER SUPPLY TO TIMER / BUZZER MODULE		
	<ul style="list-style-type: none"> Locate timer / buzzer module. Measure voltage on the BL / R wire at the timer / buzzer module connector. Is voltage greater than 10 volts? 	Yes No	GO to A14. SERVICE BL / R wire between the interior fuse panel and timer / buzzer module.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A — TIMER / BUZZER WARNING SYSTEM (Continued)									
TEST STEP		RESULT	ACTION TO TAKE						
A14	CHECK WIRES TO DOOR COURTESY LAMP SWITCHES								
	<ul style="list-style-type: none"> Disconnect ignition key relay connector. Locate door courtesy lamp switches. Measure resistance(s) of the R / Y wire between the ignition key relay and door courtesy lamp switches: Are resistance(s) less than 5 ohms? 	Yes No	GO to A15 . SERVICE R / Y wire(s).						
A15	CHECK OPERATION OF DOOR COURTESY SWITCHES								
	<ul style="list-style-type: none"> Disconnect door courtesy switches. Measure resistance from the R / Y terminal on each switch to the switch case. <table border="1"> <thead> <tr> <th>Switch Position</th> <th>Resistance</th> </tr> </thead> <tbody> <tr> <td>Depressed</td> <td>Greater than 10,000 ohms</td> </tr> <tr> <td>Released</td> <td>Less than 5 ohms</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Are resistance(s) OK? 	Switch Position	Resistance	Depressed	Greater than 10,000 ohms	Released	Less than 5 ohms	Yes No	GO to A16 . REPLACE door courtesy lamp switch in question.
Switch Position	Resistance								
Depressed	Greater than 10,000 ohms								
Released	Less than 5 ohms								
A16	CHECK FOR SHORT TO GROUND								
	<ul style="list-style-type: none"> Disconnect ignition key relay. Leave door courtesy lamp switches disconnected. Measure resistance between the R / Y wire at the ignition key relay connector and ground. Is resistance greater than 10,000 ohms? 	Yes No	GO to A17 . SERVICE R / Y wire.						
A17	CHECK WIRE FROM IGNITION KEY RELAY TO TIMER / BUZZER MODULE								
	<ul style="list-style-type: none"> Locate ignition key relay and timer / buzzer module. Measure resistance of the BL / BK wire between the ignition key relay and the timer / buzzer module. Is resistance less than 5 ohms? 	Yes No	GO to A18 . SERVICE BL / BK wire.						
A18	CHECK FOR SHORT TO GROUND								
	<ul style="list-style-type: none"> Locate and disconnect ignition key relay, timer / buzzer module, and turbo overboost relay. Measure resistance between BL / BK wire at the timer / buzzer module connector and ground. Is resistance less than 5 ohms? 	Yes No (Non-Turbo) No (Turbo)	SERVICE BL / BK from the timer / buzzer module to the ignition key relay and / or turbo overboost relay. GO to A25 . GO to A19 .						
A19	CHECK WIRE FROM TIMER / BUZZER MODULE TO TURBO OVERBOOST RELAY (TURBO ONLY)								
	<ul style="list-style-type: none"> Locate timer / buzzer module and turbo overboost relay. Measure resistance of the BL / BK wire between the turbo overboost relay and the timer / buzzer module. Is resistance less than 5 ohms? 	Yes No	GO to A20 . SERVICE BL / BK wire.						
A20	CHECK TURBO OVERBOOST RELAY GROUND (TURBO ONLY)								
	<ul style="list-style-type: none"> Locate turbo overboost relay. Measure resistance between BK wire at the turbo overboost relay connector and ground. Is resistance less than 5 ohms? 	Yes No	GO to A21 . SERVICE BK wire.						
A21	CHECK TURBO OVERBOOST RELAY (TURBO ONLY)								
	<ul style="list-style-type: none"> Locate and remove turbo overboost relay. Measure resistance across BL / BK terminal and BK terminal on the relay. Is resistance greater than 10,000 ohms? Apply 12 volts to the LG / BK terminal on the relay. Ground Y / GN terminal on the relay. Measure resistance across the BL / BK terminal and BK terminal on the relay. Is resistance less than 5 ohms? 	Yes No	GO to A22 . REPLACE turbo overboost relay.						

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A—TIMER/BUZZER WARNING SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE						
A22	CHECK WIRE TO THE BOOST PRESSURE SWITCH (TURBO ONLY)								
	<ul style="list-style-type: none">Disconnect boost pressure switch.Disconnect turbo overboost relay.Measure resistance of LG /BK wire between the turbo overboost relay and the boost pressure switch.Is resistance less than 5 ohms?	Yes No	<ul style="list-style-type: none">GO to A23.SERVICE LG /BK wire from turbo overboost relay to boost pressure switch.						
A23	CHECK OPERATION OF BOOST PRESSURE SWITCH (TURBO ONLY)								
	<ul style="list-style-type: none">Disconnect boost pressure switch connector.Connect a pressure tester to the boost pressure switch.Measure resistance across the terminals of the boost pressure switch.Compare readings with the following chart.	Yes No	<ul style="list-style-type: none">GO to A24.REPLACE boost pressure switch.						
<table><tr><th>Pressure</th><th>Resistance</th></tr><tr><td>0 kPa (0 psi)</td><td>Over 10,000 ohms</td></tr><tr><td>72-80 kPa (10-12 psi)</td><td>Under 5 ohms</td></tr></table>		Pressure	Resistance	0 kPa (0 psi)	Over 10,000 ohms	72-80 kPa (10-12 psi)	Under 5 ohms		
Pressure	Resistance								
0 kPa (0 psi)	Over 10,000 ohms								
72-80 kPa (10-12 psi)	Under 5 ohms								
	<ul style="list-style-type: none">Are measurements OK?								
A24	CHECK BOOST PRESSURE SWITCH GROUND (TURBO ONLY)								
	<ul style="list-style-type: none">Locate and disconnect boost pressure switch.Measure resistance between the BK wire at the boost pressure switch and ground.Is resistance less than 5 ohms?	Yes No	<ul style="list-style-type: none">GO to A25.SERVICE BK wire.						
A25	CHECK TIMER /BUZZER MODULE GROUND								
	<ul style="list-style-type: none">Disconnect timer /buzzer module.Measure resistance between the BK wire at timer /buzzer module connector and ground.Is resistance less than 5 ohms?	Yes No	<ul style="list-style-type: none">GO to A26.SERVICE BK wire.						
A26	CHECK WIRE FROM TIMER /BUZZER MODULE TO SAFETY BELT SWITCH								
	<ul style="list-style-type: none">Locate and disconnect safety belt switch connector.Measure resistance of the BR wire between the timer /buzzer module to the safety belt switch.Is resistance less than 5 ohms?	Yes No	<ul style="list-style-type: none">GO to A27.SERVICE BR wire.						
A27	CHECK SAFETY BELT SWITCH GROUND								
	<ul style="list-style-type: none">Locate and disconnect safety belt switch.Measure resistance between the BK wire at the safety belt switch and ground.Is resistance less than 5 ohms?	Yes No	<ul style="list-style-type: none">GO to A28.SERVICE BK wire.						
A28	CHECK SAFETY BELT SWITCH OPERATION								
	<ul style="list-style-type: none">Place a jumper wire from the BR wire at the safety belt switch to ground.Does timer /buzzer operate correctly?	Yes No	<ul style="list-style-type: none">REPLACE safety belt switch.REPLACE timer / buzzer module.						

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM

TEST STEP		RESULT	ACTION TO TAKE
B1	CHECK FUSE		
	<ul style="list-style-type: none"> Locate fuse panel. Check 10 amp METER fuse. Is fuse OK? 	Yes No	<ul style="list-style-type: none"> GO to B4. GO to B2.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
B2	CHECK SYSTEM		
	<ul style="list-style-type: none"> Replace 10 amp METER fuse. Key ON. Does fuse fail again? 	Yes No	GO to B3 . GO to B4 .
B3	CHECK FOR SHORTS TO GROUND		
	<ul style="list-style-type: none"> Replace fuse. Locate and disconnect interior fuse panel connector. Locate and disconnect instrument cluster connector. Measure resistance between the BK/Y wire at interior fuse panel connector and ground. Is resistance less than 5 ohms? 	Yes No	SERVICE BK/Y wire from interior fuse panel to instrument cluster. GO to B4 .
B4	CHECK POWER SUPPLY TO INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> Locate instrument cluster 12-pin connector. Key ON. Measure voltage on the BK/Y wire at the instrument cluster 12-pin connector. Is the voltage greater than 10 volts? 	Yes No	GO to B5 . SERVICE BK/Y wire.
B5	FAULT SYMPTOM CHART		
	<ul style="list-style-type: none"> Inspect which indicator lamp(s) are not operating correctly. 	Brake Warning MIL (Check Engine) Charge Warning Manual Shift (ATX) Air Bag Safety Belt Warning	GO to B6 . GO to B11 . GO to B14 . GO to B17 . GO to B23 . GO to B26 .
B6	CHECK BRAKE WARNING INDICATOR LAMP		
	<ul style="list-style-type: none"> Key OFF. Locate instrument cluster 12-pin connector. Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the BR/W wire (brake warning indicator lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B8 . GO to B7 .
B7	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> Replace bulb. Key OFF. Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the BR/W wire (brake warning indicator lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B8 . SERVICE instrument cluster circuit board.
B8	CHECK WIRE(S) TO BRAKE SWITCH		
	<ul style="list-style-type: none"> Key OFF. Locate instrument cluster 8-pin connector. Measure resistance from the instrument cluster BR/W wire to both the brake fluid level switch and the parking brake switch. Are the resistance(s) less than 5 ohms? 	Yes No	GO to B9 . SERVICE BR/W wire.
B9	CHECK BRAKE SWITCH(ES) GROUND		
	<ul style="list-style-type: none"> Key OFF. Measure resistance of the brake fluid level switch (BK wire) and the parking brake switch casing to ground. Are resistance(s) less than 5 ohms? 	Yes No	GO to B10 . SERVICE grounds as needed.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
B10	CHECK BRAKE SWITCH(ES) OPERATION		
	<ul style="list-style-type: none"> Locate parking brake and brake fluid level switches. Key ON. Using a jumper wire, connect the BR / W wire of the parking brake switch to ground. Does brake warning indicator lamp operate correctly? Using a jumper wire, connect BR / W wire of the brake fluid level switch to ground. Does brake warning indicator lamp operate correctly? 	Yes No	RETURN to condition chart. REPLACE switch in question.
B11	CHECK MALFUNCTION INDICATOR LAMP (MIL) (CHECK ENGINE)		
	<ul style="list-style-type: none"> Key OFF. Apply 12 volts to the BK / Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the LG / R wire (check engine lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B13. GO to B12.
B12	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> Replace bulb. Key OFF. Apply 12 volts to the BK / Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the LG / R wire (check engine lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B13. SERVICE instrument cluster circuit board.
B13	CHECK WIRE TO PCM		
	<ul style="list-style-type: none"> Key OFF. Disconnect the 8-pin instrument cluster connector. Locate PCM. Measure resistance of LG / R wire between the instrument cluster and the PCM. Is resistance less than 5 ohms? 	Yes No	REFER to Powertrain Control/Emissions Diagnosis Manual. ² SERVICE LG / R wire.
B14	CHECK CHARGE WARNING INDICATOR LAMP		
	<ul style="list-style-type: none"> Key OFF. Locate instrument cluster 12-pin connector. Apply 12 volts to the BK / Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the W / BK wire (charge warning indicator lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B16. GO to B15.
B15	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> Replace bulb. Key OFF. Apply 12 volts to the BK / Y wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the W / BK wire (charge warning indicator lamp) at the instrument cluster 8-pin connector. Does lamp operate correctly? 	Yes No	GO to B16. SERVICE instrument cluster circuit board.
B16	CHECK WIRE TO GENERATOR		
	<ul style="list-style-type: none"> Key OFF. Disconnect 8-pin instrument cluster connector. Disconnect the generator connector. Measure resistance of W / BK wire between the instrument cluster connector and the generator. Is resistance less than 5 ohms? 	Yes No	REFER to Section 14-00. SERVICE W / BK wire.

2 Can be purchased as a separate item.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
B17	CHECK MANUAL SHIFT INDICATOR LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BR/Y wire (manual shift indicator lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	► GO to B19 . ► GO to B18 .
B18	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Replace bulb. ● Key OFF. ● Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BR/Y wire (manual shift indicator lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	► GO to B19 . ► SERVICE instrument cluster circuit board.
B19	CHECK WIRE TO TRANSAXLE CONTROL MODULE (TCM)		
	<ul style="list-style-type: none"> ● Key OFF. ● Disconnect 12-pin instrument cluster connector. ● Locate transaxle control module (TCM). ● Measure resistance of BR/Y wire between the instrument cluster and the TCM. ● Is resistance less than 5 ohms? 	Yes No	► REFER to Section 07-01. ► SERVICE BR/Y wire.
B20	CHECK WIRE TO MANUAL SHIFT SWITCH		
	<ul style="list-style-type: none"> ● Locate and disconnect the TCM and manual shift switch connectors. ● Measure the resistance of the BR/BK wire between the TCM and manual shift switch connectors. ● Is the resistance less than 5 ohms? 	Yes No	► GO to B21 . ► SERVICE the BR/BK wire.
B21	CHECK MANUAL SHIFT SWITCH		
	<ul style="list-style-type: none"> ● Disconnect the manual shift switch connector. ● Measure the resistance between the BR/BK and BK terminals on the manual shift switch. ● Is the resistance greater than 10,000 ohms? 	Yes No	► GO to B22 . ► REPLACE the manual shift switch.
B22	CHECK MANUAL SHIFT SWITCH GROUND		
	<ul style="list-style-type: none"> ● Disconnect the manual shift switch connector. ● Measure the resistance between the BK wire at the manual shift switch connector and ground. ● Is the resistance less than 5 ohms? 	Yes No	► REFER to the Powertrain Control/Emission Diagnosis Manual. ³ ► SERVICE the BK wire.
B23	CHECK AIR BAG INDICATOR LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the Y/BK wire (air bag indicator lamp) at the instrument cluster 10-pin connector. ● Does lamp operate correctly? 	Yes No	► GO to B25 . ► GO to B24 .
B24	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Replace bulb. ● Key OFF. ● Apply 12 volts to the BK/Y wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the Y/BK wire (air bag indicator lamp) at the instrument cluster 10-pin connector. ● Does lamp operate correctly? 	Yes No	► GO to B25 . ► SERVICE instrument cluster circuit board.

3 Can be purchased as a separate item.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
B25	CHECK WIRE TO AIR BAG DIAGNOSTIC MODULE		
	<ul style="list-style-type: none"> ● Key OFF. ● Disconnect 10-pin instrument cluster connector. ● Locate air bag diagnostic module. ● Measure resistance of Y / BK wire between the instrument cluster and the air bag diagnostic module. ● Is resistance less than 5 ohms? 	Yes No	REFER to Section 01-20B. SERVICE Y / BK wire.
B26	CHECK SAFETY BELT WARNING INDICATOR LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 10-pin connector. ● Apply 12 volts to the BK / Y wire at the instrument cluster 10-pin connector. ● Using a jumper wire, ground the GN / O wire (safety belt warning indicator lamp) at the instrument cluster 10-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B28 . GO to B27 .
B27	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Replace bulb. ● Key OFF. ● Apply 12 volts to the BK / Y wire at the instrument cluster 10-pin connector. ● Using a jumper wire, ground the GN / O wire (safety belt warning indicator lamp) at the instrument cluster 10-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B28 . SERVICE instrument cluster circuit board.
B28	CHECK WIRE TO TIMER / BUZZER MODULE		
	<ul style="list-style-type: none"> ● Key OFF. ● Disconnect 10-pin instrument cluster connector. ● Locate timer / buzzer module. ● Measure resistance of GN / O wire between the instrument cluster and the timer / buzzer module. ● Is resistance less than 5 ohms? 	Yes No	REFER to Pinpoint Test A—Timer / Buzzer Warning System in this section. SERVICE GN / O wire.
B29	CHECK POWER SUPPLY TO INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Key ON. ● Locate instrument cluster. ● Place combination switch in the LH turn position. ● Disconnect 12-pin instrument cluster connector. ● Measure voltage on the GN / BK wire at the instrument cluster 12-pin connector. ● Does voltage flash between 0 and 12 volts? 	Yes No	Go to B30 . SERVICE GN / BK wire.
B30	CHECK LH TURN SIGNAL LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Apply 12 volts to the GN / BK wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BK wire (LH turn signal lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B32 . GO to B31 .
B31	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Replace bulb. ● Key OFF. ● Apply 12 volts to the GN / BK wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BK wire (LH turn signal lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B32 . SERVICE instrument cluster circuit board.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)

TEST STEP		RESULT	ACTION TO TAKE
B32	CHECK GROUND		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Disconnect 12-pin instrument cluster connector. ● Measure resistance between BK wire at the instrument cluster connector and ground. ● Is resistance less than 5 ohms? 	Yes No	RETURN to condition chart. SERVICE BK wire.
B33	CHECK POWER SUPPLY TO INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Key ON. ● Locate instrument cluster 12-pin connector. ● Place combination switch in RH turn position. ● Disconnect the 12-pin instrument cluster connector. ● Measure voltage on the GN / W wire at the instrument cluster. ● Does voltage flash between 0 and 12 volts? 	Yes No	GO to B34. SERVICE GN / W wire.
B34	CHECK RH TURN SIGNAL LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Apply 12 volts to the GN / W wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BK wire (RH turn signal lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B36. GO to B35.
B35	CHECK INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Replace bulb. ● Key OFF. ● Apply 12 volts to the GN / W wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BK wire (RH turn signal lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B36. SERVICE instrument cluster circuit board.
B36	CHECK GROUND		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Disconnect 12-pin instrument cluster connector. ● Measure resistance between BK wire at the instrument cluster connector and ground. ● Is resistance less than 5 ohms? 	Yes No	RETURN to condition chart. SERVICE BK wire.
B37	CHECK POWER SUPPLY TO INSTRUMENT CLUSTER		
	<ul style="list-style-type: none"> ● Key ON. ● Locate instrument cluster 12-pin connector. ● Place combination switch in the HIGH beam position. ● Disconnect the 12-pin instrument cluster connector. ● Measure voltage on the R / W wire at the instrument cluster 12-pin connector. ● Is voltage greater than 10 volts? 	Yes No	GO to B38. SERVICE R / W wire.
B38	CHECK HIGH BEAM INDICATOR LAMP		
	<ul style="list-style-type: none"> ● Key OFF. ● Locate instrument cluster 12-pin connector. ● Apply 12 volts to the R / W wire at the instrument cluster 12-pin connector. ● Using a jumper wire, ground the BK wire (high beam indicator lamp) at the instrument cluster 12-pin connector. ● Does lamp operate correctly? 	Yes No	GO to B40. GO to B39.

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST B—WARNING INDICATOR LAMPS SYSTEM (Continued)


TEST STEP		RESULT	ACTION TO TAKE
B39	CHECK INSTRUMENT CLUSTER <ul style="list-style-type: none"> Replace bulb. Key OFF. Apply 12 volts to the R/W wire at the instrument cluster 12-pin connector. Using a jumper wire, ground the BK wire (high beam indicator lamp) at the instrument cluster 12-pin connector. Does lamp operate correctly? 	Yes	▶ GO to B40 .
		No	▶ SERVICE instrument cluster circuit board.
B40	CHECK GROUND <ul style="list-style-type: none"> Key OFF. Locate instrument cluster 12-pin connector. Disconnect 12-pin instrument cluster connector. Measure resistance between BK wire at the instrument cluster connector and ground. Is resistance less than 5 ohms? 	Yes	▶ RETURN to condition chart.
		No	▶ SERVICE BK wire.

REMOVAL AND INSTALLATION

Warning/Indicator Lamp Bulbs

Removal and Installation

1. Remove instrument cluster. Refer to Section 13-01.
2. Replace bulb(s).
3. Install instrument cluster.




K12931-A

Parking Brake Switch

Removal

1. Remove rear console. Refer to Section 01-12.
2. Remove retaining screws and parking brake warning indicator lamp switch from parking brake lever.



H6776-A

Installation

1. Install parking brake warning indicator lamp switch onto parking brake lever.
2. Adjust switch as required to operate warning lamp in instrument cluster when brake handle is lifted more than two notches.
3. Install console. Refer to Section 01-12.

High Beam Switch

Removal and Installation

The high beam and flash-to-pass switches are part of the turn signal switch assembly. Refer to Section 11-05 for service.

REMOVAL AND INSTALLATION (Continued)**Brake Fluid Level Switch****Removal and Installation**

The low brake fluid level switch is located in the base of the master cylinder reservoir. Refer to Section 06-00 for service.

Safety Belt Switch**Removal and Installation**

1. Remove front safety belt retractor. Refer to Section 01-20A.

2. Disconnect electrical wiring from switch.
3. Remove switch.
4. To install, reverse Removal procedure.